

Thank you for purchasing the Vivitar Clear Wireless Handset, item FBRPHRB. Use your handset to take calls or play audio. Please read this manual carefully **FIRST** in order to get the most out of your handset.

Charging

Use the included Micro USB cable to power your handset. Insert the Micro USB end into the charging port on your handset. Insert the standard USB end into a suitable USB power port. The indicator light will turn red while charging. When charging is complete, the light will turn blue for 30 seconds and then power off.

Bluetooth Pairing

Press and hold the Power Button for 3-4 seconds to power ON your handset. You will hear the phrase "Power On." The indicator light will flash blue to indicate your device has entered Bluetooth pairing mode.

Go to the Bluetooth settings menu on your smartphone. Make sure that Bluetooth is turned ON, then connect to the device listed as "Retro Receiver."

The Indicator light will remain blue to indicate that your handset is paired with your device.


Music/Call Controls

Press and hold the **Volume + Button** to skip to the next song. Press to increase volume.

Press and hold the **Power Button** for 3-4 seconds to power on or power off your headset.

Press once to play or pause a song.
Press once to answer or end a phone call.
Press and hold to reject an incoming call.

Press and hold the **Volume - Button** to return to the last song. Press and hold to decrease volume.





Package Contents

- Clear Wireless Handset
- USB Charging Cable
- User's Manual With One Year Warranty Information

Specifications

- Battery Type:** 3.7V, 250mAh Li-ion Battery
- Speaker Output Power:** 3W
- Bluetooth Version:** V5.0
- Bluetooth Range:** Approximately 32ft (10m)
- Charging Time:** Approximately 3-4 hours
- Playtime Time:** Approximately 1.5-2.5 hours

Safety Precautions

When using your handset, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR HANDSET.
2. Do not submerge your handset in water.
3. Only clean using a clean cloth.
4. Do not allow children to play with this product. Parental supervision is advised.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.



BATTERY WARNING

- The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepared.

FCC Statement

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.