

TWS挂耳蓝牙耳机

>>> 说明书 <<<



MR-G37
EARPHONE

>>> 产品介绍 <<<

本产品为无线蓝牙耳机，蓝牙耳机是无线耳机技术发展的最新成果，蓝牙耳机具有体积小、重量轻、携带方便、使用简单、通话清晰、音质优美、续航能力强等特点，是无线耳机发展的最新成果。本产品采用蓝牙技术，可实现手机、电脑、平板、电视等多种设备的无线连接，使用方便快捷。本产品采用高品质材料，外观时尚，手感舒适，是您商务、休闲、运动的理想选择。

>>> 第一部分挂耳式蓝牙耳机 <<<



- 指示灯
- 充电触点

>>> 耳机充电操作 <<<

本产品采用USB-C接口充电，充电时将耳机放入充电盒，充电盒底部有充电触点，与充电底座接触即可充电。充电盒支持快充功能，充电15分钟即可使用2小时。充电盒支持无线充电，可将充电盒放在无线充电底座上即可充电。充电盒支持快充功能，充电15分钟即可使用2小时。充电盒支持无线充电，可将充电盒放在无线充电底座上即可充电。

>>> 开关机(蓝牙耳机开机) <<<

开机



长按电源键3秒，耳机开机，指示灯亮起。长按电源键3秒，耳机关机，指示灯熄灭。

关机



长按电源键3秒，耳机关机，指示灯熄灭。长按电源键3秒，耳机开机，指示灯亮起。

>>> 接听/挂断/拒接电话 <<<



接听电话：短按电源键2秒。挂断电话：长按电源键3秒。拒接电话：短按电源键1秒。

>>> 音乐上/下曲切换 <<<



音乐上一曲：短按音量减键2秒。音乐下一曲：短按音量加键2秒。音乐播放/暂停：短按电源键2秒。

>>> 蓝牙耳机配对步骤(双耳同时使用) <<<

方法①



长按电源键5秒，耳机进入配对模式，指示灯闪烁。将耳机放入手机蓝牙列表，点击连接即可。

方法②



长按电源键5秒，耳机进入配对模式，指示灯闪烁。将耳机放入手机蓝牙列表，点击连接即可。

>>> 包内容 <<<



- 蓝牙耳机
- 充电底座
- 说明书
- 保修卡

合格证

QC Passed

产品保修卡

请妥善保管此卡，以备售后服务之用。

产品名称	产品型号
蓝牙耳机	MR-G37
制造商	深圳市某某科技有限公司
生产日期	2024-01-01

品牌	产品型号	保修期限
蓝牙耳机	MR-G37	12个月
充电底座	MR-G37	12个月

TWS WIRELESS EARBUDS
MR-G37
MANUAL

Product introduction
 Thank you for purchasing our product. This product is a TWS (true wireless) Bluetooth headset, which can be used without a cable. It has a long standby time and a clear sound quality, providing you with a better listening experience. It is suitable for various occasions, such as sports, travel, and work. It is a good choice for you to use.

Charging Instruction
 1. Make sure the headset and charging case are fully charged before use.
Charging case charging
 1. Connect the charging case to the power supply (USB or power adapter).
 2. The LED light on the charging case will turn on, indicating that the case is charging.
 3. The LED light on the charging case will turn off, indicating that the case is fully charged.

Switch/Bluetooth headset/turn off
Power on
 1. Press the power button on the charging case for 3 seconds.
 2. The LED light on the charging case will turn on, indicating that the headset is powered on.
Power off
 1. Press the power button on the charging case for 3 seconds.
 2. The LED light on the charging case will turn off, indicating that the headset is powered off.

Music up/down switch
 1. Press the up/down button on the headset to play/pause music.
 2. Press the up/down button on the headset to skip forward/backward.

TWS Pairing Method (TWS Mode)
Method one
 1. Press the power button on the charging case for 3 seconds.
 2. The LED light on the charging case will turn on, indicating that the headset is in pairing mode.
Method two
 1. Press the power button on the charging case for 3 seconds.
 2. The LED light on the charging case will turn on, indicating that the headset is in pairing mode.

Package content
 1. TWS Wireless Earbuds (Left/Right)
 2. Charging Case
 3. User Manual
 4. Warranty Card

Product warranty card
 This card is the warranty card for the product. It is valid for 12 months from the date of purchase.
 Product Name: MR-G37
 Date of purchase: _____
 Customer Name: _____
 Update Information: _____

Charging Warning
 Please do not use the headset for a long time. It may cause the battery to overheat and damage the headset. Please use the headset for a short time and rest it for a while.

Product warranty card
 This card is the warranty card for the product. It is valid for 12 months from the date of purchase.
 Product Name: MR-G37
 Date of purchase: _____
 Customer Name: _____
 Update Information: _____

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.