

AGM


Quick Start Guide


AGM_PAD_T2



NOTICE:

Features of the product and its accessories described herein rely on the software, phone internal memory and local networks, and may not be activated or may be limited by local network operators or service providers. Therefore, the descriptions herein may not exactly match the purchased product or its accessories. The manufacturer reserves the rights to change or modify any information or specifications contained in this manual without prior notice or obligation. The manufacturer is not responsible for the legitimacy or quality of any products that you may upload or download through this device including but not limited to text, images, music, movies, and non-integral software. Any consequences arising from the usage of the preceding products on this device is the responsibility of.

Overview



1> Power Key.

Long press power key to power phone on/off.
Short press power key to lock/unlock the screen.

2> Volume Key.

Press to increase/decrease the phone volume.
Press to mute the phone during an incoming call.

3> Sensors.

Optical proximity sensor and Ambient light sensor.

4> Front camera. (8MP)

Takes front facing photos.

5> LOUDSPEAKER.

6> Display.

10.95" inches FHD.

7> Microphone.

For talking and voice recording. Do not touch with hard pin.

8> SIM/SD Tray.

Supports Nano SIM and Micro SD card.

9> LOUDSPEAKER.

10> USB Type-Cport.

11> LED.

12> Macro camera. (2MP)



13> Main camera. (13MP)

Takes photos and videos.

GETTING STARTED

Installing the SIM and Micro SD card:

1. Use metal ejector pin provided to open the SIM tray.
2. Pull out the SIM tray.
3. Place Nano-SIM in inside position.
4. Place Nano-SIM or Micro SD card in outside position.
5. Make sure that the Nano-SIM and Micro SD card the cut corner aligned with tray in the correct position as per the diagram shown above.



NOTE:

1. * For some versions, The device does not support 2 SIM cards data services working together. When inserting 2 SIM cards, you can only choose one of the 2 SIM cards to use 4G services. The device supports dual SIM dual standby but single pass. This means that you cannot use both SIM cards for calls or data services simultaneously.
2. Nano-SIM and Micro SD card socket can only be used for either Nano-SIM or Micro SD card. Place the Nano-SIM vertically or place Micro SD card horizontally.
3. SIM card adapter. A cut SIM card or any other non-standard cards are not allowed. Those non-standard cards may not be recognized by the phone and can damage the tray.

***5.2 GHz band is restricted to indoor use due to the Radio Law.**


***Following functions are disabled in AGM_PAD_T2 WIFI Version: Nano-SIM.**

BATTERY AND CHARGING

Note: The device battery is not removable.

Charging the PAD:

1. Connect the USB power cable to the port. Be careful not to use excessive force when plugging the cable. Any damage caused by attempting to insert the connector incorrectly is not covered by the warranty.
2. Connect the USB power cable to the charging power adapter.
 - * The device supports CE/REACH/WEEE/FCC/TELEC or equivalent certified chargers.
 - * The recommended charger output is 9V $\overline{=}$ 2A.Uncertified equipment may cause damage to the device or cause batteries to explode.
3. Plug the charger into an AC mains socket.
4. When charging is complete, remove the cable from the device.



Tips:

1. The optimum working temperature for the device is from 0°C~40°C. Charging the device outside this temperature range will damage the battery and shorten battery life.
 - * Please do not charge the device under extremely low or high temperature, Please charge the device under 5°C~ 40°C. Otherwise the battery will be damaged or exploded.

2. Please use the certified charger and cable to ensure maximum performance and safety.
3. Please note that the battery will still discharge itself even when the device is not in use and switched off. If you plan to not use the unit for an extended period, you should still charge it at least every two months to prevent complete power loss and to protect your data.

Quick Start Guide

Powering On the Device:

Press and hold the power button for 5 seconds, release the button after the device vibrates. Your device will start, and you'll see the brand's startup screen.

Unlocking the Device:

By default, press the power button to unlock the screen, and swipe up to unlock the device. Users can also set different screen unlock methods according to their preferences, such as slide, pattern, PIN code, password, etc.

Taking Screenshots:

Simultaneously press the power button and the volume down button.

Quick Access Menu:

Pull down from the status bar to open the notification panel. Users can select shortcut icons based on their needs to activate/deactivate quick functions. Here, you can find quick functions like internet, Bluetooth, flashlight, alarm, airplane mode, power-saving mode, etc.

Desktop Settings:

Long press on an empty space on the screen, choose wallpaper and style, widgets, and home screen settings. Users can customize the device desktop according to their preferences. For example, dragging the "Clock" widget to an empty space on the desktop will display and allow its use.

Display Settings:

Go to Settings > Display > Enter various menus to complete settings according to your needs. Here, you can find functions like brightness, screen lock, display size, and font.

Sound and Vibration Settings:

Go to Settings > Sound and Vibration > Enter various menus to complete settings according to your needs. Here, you can find settings for alarm volume, do not disturb mode, device ringtone, etc.

Other Settings:

Go to Settings > System > Enter various menus to complete settings according to your needs.

Here, you can find functions like language, navigation bar, system updates, date and time, etc.

*To change the system language and switch input methods, you need to enter the "Language" menu.

WARNING



At full volume, extended use of the mobile audio player may damage the user's hearing.

DISPOSAL AND RECYCLING INFORMATION



This symbol on the device (and any included batteries) indicates that they should not be disposed of as normal household garbage. Do not dispose of the device or batteries as unsorted municipal waste. The device (and any batteries) should be handed over to a certified collection point for recycling or proper disposal at the end of their life.

Basic information of manufacturer

GUANGDONG AIJIEMO ELECTRONIC INDUSTRY CO., LTD
Copyright AGM Mobile Limited 2024. All rights reserved.

THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY,
AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

IC Statement information

ISED Statement

English: This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This EUT is compliance with SAR for general population/ uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209. This equipment should be installed and operated with minimum distance 0 mm between the radiator and your body. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

French:

L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L' exploitation est autorisée aux deux conditions suivantes:

- (1) L' appareil ne doit pas produire de brouillage;
- (2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

Cet EUT est conforme au SAR pour la population générale/limites d'exposition non contrôlées dans IC RSS-102 et a été testé conformément aux méthodes et procédures de mesure spécifiées dans IEEE 1528 et CEI 62209. Cet équipement doit être installé et utilisé à une distance minimale de 0 mm entre le radiateur et votre corps. Cet appareil et ses antennes ne doivent pas être situés ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

L'appareil destiné à fonctionner dans la bande 5150-5250 MHz est uniquement destiné à une utilisation en intérieur afin de réduire le potentiel d'interférences nuisibles aux systèmes mobiles par satellite cocanaux.

FCC RF EXPOSUR INFORMATION:

RF Exposure Information:

This product is compliance to FCC RF Exposure requirements and refers to FCC website <https://apps.fcc.gov/oetcf/eas/reports/GenericSearch.cfm> Search for FCC ID: 2A3DR-AGMPADT2 to gain further.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Hereby, (GUANGDONG AIJIEMO ELECTRONIC INDUSTRY CO., LTD) declare that the product is compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: XXX



The maximum results of SAR as follows:

Body-worn (with 0mm separation): 1.402W/Kg

limbs (with 0mm separation): 1.402W/Kg

Caution:

For Adapter: Shall be installed near the equipment and shall be easily accessible.

For Battery: Risk of explosion battery is replaced by an incorrect type, dispose of used batteries according to the instructions.

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Only can use the adapter as below:

Manufacturer: Shenzhen Huajin Electronics Co., Ltd

Model Name: HJ-FC008K7-EU

Input: 100-240V~ 50/60Hz 0.6A

Output: 5.0V 3.0A 15.0W OR 9.0V 2.0A 18.0W OR 12.0V 1.5A 18.0W

(class II, LPS, 40° C)

The plug could be disconnected from adapter.

Technology	Frequency MHz		RF Power
	From	To	
GSM900	880	915	32.42dBm
DCS1800	1710	1785	30.00dBm
UTRA Band I	1920	1980	24.31dBm
UTRA Band VIII	880	915	24.90dBm
E-UTRA Band 1	1920	1980	23.34dBm
E-UTRA Band 3	1710	1785	23.66dBm
E-UTRA Band 7	2500	2570	23.71dBm
E-UTRA Band 8	880	915	24.52dBm
E-UTRA Band 20	832	862	24.42dBm
E-UTRA Band 28	703	748	24.13dBm
E-UTRA Band 40	2300	2400	23.67dBm
Bluetooth BR/EDR	2402	2480	4.87dBm
Bluetooth BLE	2402	2480	-1.45dBm
WLAN	2412	2472	16.12dBm
RLAN	5180	5240	14.31dBm
RLAN	5745	5825	10.94dBm
GPS	1559	1610	--
GLONASS	1559	1610	--
BDS	1559	1610	--
FM	87.5	108	--

This device is restricted to indoor use only when operating in 5150 MHz to 5250 MHz in all EU member states.

Hereby, (GUANGDONG AIJIEMO ELECTRONIC INDUSTRY CO., LTD) declare that the product is compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.xxyyy.com



The maximum results of SAR as follows:

Body-worn (with 0mm separation): 1.402W/Kg

limbs (with 0mm separation): 1.402W/Kg

Caution:

For Adapter: Shall be installed near the equipment and shall be easily accessible.

For Battery: Risk of explosion battery is replaced by an incorrect type, dispose of used batteries according to the instructions.

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Only can use the adapter as below:

Manufacturer: Shenzhen Huajin Electronics Co., Ltd

Model Name: HJ-FC008K7-EU

Input: 100-240V~ 50/60Hz 0.6A

Output: 5.0V 3.0A 15.0W OR 9.0V 2.0A 18.0W OR 12.0V 1.5A 18.0W

(class II, LPS, 40° C)

The plug could be disconnected from adapter.

Technology	Frequency MHz		RF Power
	From	To	
GSM900	880	915	32.42dBm
DCS1800	1710	1785	30.00dBm
UTRA Band I	1920	1980	24.31dBm
UTRA Band VIII	880	915	24.90dBm
E-UTRA Band 1	1920	1980	23.34dBm
E-UTRA Band 3	1710	1785	23.66dBm
E-UTRA Band 7	2500	2570	23.71dBm
E-UTRA Band 8	880	915	24.52dBm
E-UTRA Band 20	832	862	24.42dBm
E-UTRA Band 28	703	748	24.13dBm
E-UTRA Band 40	2300	2400	23.67dBm
Bluetooth BR/EDR	2402	2480	4.87dBm
Bluetooth BLE	2402	2480	-1.45dBm
WLAN	2412	2472	16.12dBm
RLAN	5180	5240	14.31dBm
RLAN	5745	5825	10.94dBm
GPS	1559	1610	--
GLONASS	1559	1610	--
BDS	1559	1610	--
FM	87.5	108	--

This device is restricted to indoor use only when operating in 5150 MHz to 5250 MHz in all EU member states.



Discover more fun by
joining AGM community.

This maunual is for reference only,the actual functions and product may be slightly different from this manual, please refer to the actual product.

EC	REP	Company:E-CrossStu GmbH
		Address:Mainzer Landstr.69,60329 Frankfurt am Main

