



1. Charging

1. Insert the earbuds into the charging case.
2. Charge the case (2.5h).

2. Pairing

1. Press the power button on the case (03").
2. The case lights up.
3. Pair with a smartphone (Bluetooth icon).

3. Call

1. Press the call button (L/R).
2. Press the call button (x1) to answer/end call.
3. Press the call button (x2) to reject call.

4. Play/Pause

1. Press the play/pause button (R).
2. Press the play/pause button (x2) to play/pause.

5. Previous/Next

1. Press the previous/next button (L).
2. Press the previous/next button (x3) to previous/next.
3. Press the previous/next button (x1) to previous/next.
4. Press the previous/next button (x1) to previous/next.

6. Volume

1. Press the volume button (R).
2. Press the volume button (x3) to increase/decrease volume.
3. Press the volume button (x1) to increase/decrease volume.
4. Press the volume button (x1) to increase/decrease volume.

7. Microphone

1. Press the microphone button (R).
2. Press the microphone button (x1) to activate/deactivate microphone.
3. Press the microphone button (x1) to activate/deactivate microphone.
4. Press the microphone button (x1) to activate/deactivate microphone.

8. Touch Sensitivity

1. Press the touch sensitivity button (L).
2. Press the touch sensitivity button (x1) to increase/decrease touch sensitivity.
3. Press the touch sensitivity button (x1) to increase/decrease touch sensitivity.
4. Press the touch sensitivity button (x1) to increase/decrease touch sensitivity.

9. Reset

1. Press the reset button (R).
2. Press the reset button (x1) to reset.

10. Settings

1. Press the settings button (L).
2. Press the settings button (x2) to settings.