
206.3 mm

Mate Wireless Charging Pad and iWatch Holder

Instruction Manual
Item: SM-2835 Model: XY-PR027



Functions:

- Wireless Charging Surface
 Watch Charging Cable Stand
- 2. Ivvalori Charging
- Type-C Input Port
 LED Indicator

What's included:

- 1 x Wirelsss Charging Pad
- 1 x USB-A to Type-C Charging Cable
 1 x Instruction Manual

Tech Specifications

- Type-C Input: 5V/1.5A
- Wireless Output: 5W

Instructions:

- Wireless Charging Mobile phones and other electronic devices:
- Connect the provided the charging cable to the Type-C input port(3) of the wireless charging pad, then connect the USB-A tip to a power source.
- LED indicator (4) will flash BLUE & RED 3 times, then glow RED to indicate the wireless charger is in standby mode
- Place the wireless charging supported mobile device on the wireless charging surface(1), LED will glow BLUE when device is charging.
- Phone will begin to charge automatically.
 Once fully charged remove the device.
- Note: When wireless charging, if the LED indicator flashes the device is either NOT a wireless charging device or there is an object between the device and charging surface interfering with the charging.

2. iWatch Charging Cable Stand:

- Insert the stand (2) into the slot of the charging surface.
- Take the USB-A or Type C tip of the iWatch charging cable(NOT INCLUDED) and run it through the front of the watch charging stand(2)
- Plug the iWatch charging cable into a power source.
- Take the round iWatch charger part of the cable (NOT INCLUDED) and place it in the designated cut out on the stand (2), if placed correctly charging surface should be flat with the stand.
- Place your iWatch on the stand (2) to begin charging. Remove it once fully charged.

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed:
- Read all the instructions before use.
 Never store or use this product in temperatures below 32°F (0°C) or above.
- 115°F (45°C).

 3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for
- more than 7 hours at a time.

 4. To reduce the risk of injury, close supervision is required when the product is used pear children.
- Do not expose the device to moisture.
- Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
- rating may result in a risk of fire or injury
 7. Do not use the device if damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- 10. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
- To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
- 12. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. You must remove attachments from the phone before charging on this device.

FCC Statement:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- Warning: Changes or modifications not expressly approved by the party responsible for combliance could void the user's authority

to operate the equipment. FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

Name of the Distributor:

Address of the Distributor:

Hialeah FL 33013 USA

FCC ID: 2ADK3-PR027

WWW PCNA COM

Made in China

6301 East 10th Avenue, Suite 110

Bulletline Inc.

to comply with the limits for a Class B digital device nursuant to part 15 of the ECC Rules. These limits are designed to provide reasonable protection. against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a narticular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

NOTE: This equipment has been tested and found

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment.
- Connect the equipment into an outlet on a circuit
- different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



MIX

Paper from responsible sources

FSC® C170910

20.0 mm

FSC

mm

31.2

MIX

Paper from responsible sources

FSC® C170910

