








<p><b>ERAZER Invested By Lenovo</b></p>  <p><b>ERAZER Wireless Earbud X5 Product Manual</b></p>	<p><b>Specification of Product</b></p> <p>Model of Product: X5 Version: V5.4 Effective Distance: Approx. 10m Speaker Diameter: φ14.2mm Impedance: 16Ω Frequency Respinse: 20Hz-20KHz Microphone Sensitivity: -38dB±1dB Earphone Input: 5V=35mA Charging Case Input: 5V=350mA Charging Case Output: 5V=70mA Earphone Battery Capacity: 35mAh Charging Case Battery Capacity: 350mAh Duration: Approx. 4 H (Earphone) Earphone Charging Time: Approx. 1.5 H Charging Time of the Charging Case: Approx. 1.5 H</p> <p><b>Item list</b></p> 	<p><b>Welcome to ERAZER Wireless Earbud</b></p>  <p><b>Take out and pair it</b></p> <p>When using it for the first time, please remove the earphones on both sides at the same time. The white and ice blue lights on the earphones flash, and the earphones will automatically pair.</p>	<p><b>How to wear headphones correctly</b></p>  <p><b>1</b></p>	 <p><b>2</b></p>	<p><b>Product Description</b></p> 	<p><b>Touch Operation</b></p> <p><b>Connect with Bluetooth device</b></p>  <p>Open the Bluetooth settings option of the Bluetooth device to be paired, enter the options and find the Bluetooth pairing name of the headset "ERAZER X5".Click the pairing name to pair.</p>	<p><b>Indicator Light Description</b></p>  <ul style="list-style-type: none"> <li>When the headset is turned on: White and ice blue lights flashing</li> <li>When the headset is turned off: The white light flashes three times and then goes out</li> <li>Successful pairing of left and right ears: White and ice blue lights flashing</li> <li>Bluetooth device successfully connected: no light</li> <li>Headphone Charging: The headphone indicator light is always white, and the ear is fully charged The white indicator light turns to ice blue and stays on for 5-10 seconds before turning off.</li> <li>Charging of the Charging case: The digital display screen of the charging case flashes, After being fully charged, the digital display screen of the charging case always shows 100.</li> </ul>		
 <p><b>Power On</b> Auto power on: The Earphone are taken out of the charging case, the Earphone will be powered on, with the prompt sound of "Du". Manual power-on: Long press for 3 seconds, the Earphone will be powered on, with the prompt sound of "Du".</p> <p><b>Power Off</b> Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du". Manual power off: Long press for 3-5 seconds, the Earphone will be powered off, with the prompt sound of "Du".</p> <p>Note: After powering on, if it is not paired with a Bluetooth device for 3 minutes, it will automatically shut down; Exceeded the effective connection distance and did not connect to the Bluetooth device, it will automatically power off after 3 minutes, with the prompt sound of "Du".</p>	<p><b>Once Press</b></p>  <p>Music mode: Play/Pause Phone mode: Call Answer/End</p> <p><b>Double Press</b></p>  <p>Double press the right ear: Volume up Double press the left ear: Volume decreases</p>	<p><b>Long Press</b></p>  <p>Wake up voice assistant</p> <p>When using both ears, press and hold the left ear multi-function button for 2 seconds to activate the voice assistant. When using one earphone, press and hold the left (or right) earphone for 2 seconds to activate the voice assistant</p> <p><b>Phone mode</b></p> <p>Press and hold the left (or right) ear multi-function button for two seconds: call rejection</p>	<p><b>Triple Press</b></p>  <p>Music mode</p> <p>Triple press on the left ear: Previous song Triple press on the right ear: next song</p> <p><b>Switch between game mode and music mode</b></p>  <p>Game mode Music mode</p> <p>Press and hold the multi-function button on the right ear for 2 seconds Press and hold again for 2 seconds</p> <p>Note 1: When using one earphone, you cannot switch between game mode and music mode. Note 2: The factory setting defaults to music mode</p>	<p><b>Clear Bluetooth pairing history</b></p> <p>When two ears cannot be paired, it is necessary to clear all connected devices and click on the left and right earphones 5 times respectively.</p>  <p><b>Wireless pairing mode</b></p> <ol style="list-style-type: none"> <li>When there is no pairing record for the left and right earphones, the left and right earphones will automatically pair after they are turned on. After successful pairing, there will be two beeps.</li> <li>When the left and right earphones have pairing records, they will automatically connect back when they are turned on, and the prompt will sound "beep"</li> </ol>	<p><b>FCC ID: 2BHJR-X5</b></p> <p>FCC Warning: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p>	<p>*RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <table border="1"> <tr> <td><b>US REP</b></td> <td>Company Name: MIRAMONT SOLUTIONS LLC Address: 34218 HOURGLASS ST, TEMECULA, CA 92592, United States Contact Name: Wenyi Wang Telephone No: (951) 401-3633 Email: scotttv6688@gmail.com</td> </tr> </table>	<b>US REP</b>	Company Name: MIRAMONT SOLUTIONS LLC Address: 34218 HOURGLASS ST, TEMECULA, CA 92592, United States Contact Name: Wenyi Wang Telephone No: (951) 401-3633 Email: scotttv6688@gmail.com	<p><b>ERAZER</b></p>
<b>US REP</b>	Company Name: MIRAMONT SOLUTIONS LLC Address: 34218 HOURGLASS ST, TEMECULA, CA 92592, United States Contact Name: Wenyi Wang Telephone No: (951) 401-3633 Email: scotttv6688@gmail.com								