

AC POWER CEILING FAN REMOTE CONTROL MANUAL



LEARNING PROCESS

NOTE: The Hand Held Remote Control System is equipped with a learning frequency function which has code combinations to prevent potential interference from other remote units.

Step: 1 Open the remote battery cover and install DC1.5V*2pcs battery.

Step: 2 turning the Receivers AC power ON.

After completing the steps above, you should be able to operate the ceiling fan and light. If the fan is not responding to the transmitter, please turn the power off to the receiver. And repeat step 1 and 2. Remove the battery if not used for long periods of time to prevent damage to the hand held remote.

FUNCTIONS OF TRANSMITTER

1. **OFF** : Press this button to turn the fan off .
2. **HIGH** : Press this button to high fan speed and LED indicator would be on.
3. **MED** : Press this button to Medium fan speed and LED indicator would be on.
4. **MLOW** : Press this button to Med. low fan speed and LED indicator would be on.
5. **LOW** : Press this button to low fan speed and LED indicator would be on.
6. **LIGHT**: Press this button to ON/OFF light kit. Long Press this button to dimmer light kit.
and LED indicator would be on.
7. When pressing remote button, the LED indicator would be on. If you press remote button and LED indicator would not be on, you should change new DC1.5V*2pcs battery .



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.