

CEILING FAN REMOTE CONTROL MANUAL

LEARNING PROCESS

NOTE : The Hand Held Remote Control System is equipped with a learning frequency function which has code combinations to prevent potential interference from other remote units


Step: 1 Open the remote battery cover and install DC12V,23A 1pc battery

Step: 2 Within 30 seconds of turning the Receivers AC power ON.






Step: 3 Press and hold remote “LEARN” key for over 3 seconds, once the receiver has detected the frequency, Then fan turn on low speed and light turn off. This will indicate the receiver has learned the frequency that was previously selected on the transmitter.

NOTE: After the AC power is on, do not press any other button on the transmitter before setting learning. Doing so will cause the procedure to fail. After completing the steps above, you should be able to operate the ceiling fan and light. If the fan is not responding to the transmitter, please turn the power off to the receiver. And repeat step 1 and 2.


NOTE: Remove the battery if not used for long periods of time to prevent damage to the hand held remote.





FUNCTIONS OF TRANSMITTER

1.  : To turn the fan off.
2.  : Turn on ceiling fan at high speed
3.  : Turn on ceiling fan at medium speed.
4.  : Turn on ceiling fan at low speed.
5.  : Tap once to activate. Light on ceiling fan blinks once to confirm Walk

Away Delay is active. The light turns off after 1 minute. Press any key to cancel function.

6.  : Home Shield--Press and hold button to activate. Light on ceiling fan blinks two times to confirm Home Shield is active. Fan remains off and the light randomly turns on for a minimum of 5 minutes and a maximum of 20 minutes. The light remains off for 60 minutes between events. To deactivate press any button once
7. : “NATURAL FLOW”, press the button for set fan speed change automatically. Press Fan Speed to deactivate.



8.  : Press and release immediately to turn on or off the light

DIMMER- Press and hold to dim or brighten lights to the desired level and release.

9. When pressing remote button, the LED indicator would be on. If you press remote button and LED indicator would not be on, you should change new DC12V,23A 1pc battery.

To assure continued FCC compliance:

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

To assure continued FCC compliance:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

Model: TRA049G1M

FCC ID : 2AQZU-18052

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.