

3. Connect WiFi

Connect Wi-Fi. Connect PC to the Wi-Fi network using the following steps.
Select the/icon from the taskbar.

Click the wifi icon to turn on the wi-fi.

•Select an access point in the list of available Wi-Fi connections. Select one of the connections to start the network connection.

Note: You may be prompted to enter a security key to activate a Wi-Fi connection.

4. Enter the BIOS setting
4. Enter the BIOS setting
The BIOS (Basic Input/ Output System) is the first software loaded
when the Mini PC starts.
Enter Bios: Click "Del" or "ESC" key.
Under normal circumstances, the default BIOS settings apply in most
cases to ensure optimum performance. Do not change the default BIOS
settings. Except for the following situation.
(You be a circumstance with the service further BIOS

Varing! Inappropriate BIOS settings may cause instability or startup Warning! Inappropriate BIOS settings may cause instability or startup failure. We strongly recommend that you can only change the BIOS settings with the help of technical service personnel.

## Precautions

 Please take extra care when executing operations that may cause damage or loss of documents.
Pay attention to virus protection during the use of mini-host, and try to use virus firewall.

3. Please turn off the mini-host and disconnect the power supply if you

 Prease tim on the mini-host and bisconnect the power supply in you don't use it for a long time.
Do not switch on and off the mini-host frequently in a short period of time. It is recommended that the interval between two startup times should be at least 10 seconds, preferably not less than 60 seconds. Pay attention to moisture-proof, and keep the use environment clean and sterilized. If there is dust on the host machine, please wipe it with a dry soft cloth.
Avoid direct exposure of strong light to mini-host, and do not approach there is a support of the strong light to mini-host, and do not approach

strong magnetic field.

7.0 on or get water, food and other fluids onto the mini–host, and do not pull the data cable, power cord, etc.

4

## **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.