
说明书材质: 125g铜版纸, 风琴折叠





Color Changing Speaker Operation Manual BMI-LEDSPKR

> FCC ID: 2AANZLEDSPKR MADE IN CHINA

Thank you for purchasing the BMI Color Changing Speaker. Please read all instructions carefully before using and retain this manual for future use and reference.

PACKAGE CONTENTS

- Color Chanaina Speaker
- · Micro USB Charging Cable
- Operation Manual

KEY FEATURES

- Compatible with Bluetooth®-enabled devices
- Built-in rechargeable battery
- High quality sound
- Built-in speaker
- Led liahts

SAFETY INSTRUCTIONS

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit of it has been exposed to water. moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.


Do not puncture or harm the exterior surface of the product in any way.

Keep the unit free from dust, lint, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device. This product is not a toy. Keep out of reach of children.

Do not expose batteries, battery pack, or batteries to installed to excessive heat, such as direct sunlight, or open flame.

DIAGRAM



- 1. DC 5V Slot
- 2. TE Slot 3. USB Slot
- 4 Power Switch
- 5. Mode Switch Button
- 6. Previous Track/Short Hold Volume Down/Long Hold
- 7. Next Track/Short Hold Volume Up/Long Hold
- 8. Flashing Lights/Short Hold No LEd lights/Short Hold

CHARGING THE SPEAKER

The speaker comes with a built-in rechargeable battery. Before using it for the first time, we recommend you charge the battery fully. Only use the supplied charge cable to charge the speaker.

Connect the USB end to a computer USB port or a USB wall charger and the micro USB to the charge port on the speaker.

A full charge of the battery takes around 2 hours. When the battery is fully charged, the LED indicator will be red light. Disconnect the speaker at this point. The speaker is ready for

When the battery is low, the speaker will turn off automatically. When this occurs, please recharge the speaker.

PROMPT NOTIFICATION

- The speaker will notify you during "Deep" with a blue light.
- The speaker will notify you when "Deep" with the sound of a

PAIRING THE SPEAKER

- 1. Ensure the speaker is turned off. If it is not, please turn off the speaker first before pairing.
- 2. Place the speaker and the Bluetooth® device to which you would like to pair it within the operating distance. We recommend keeping the two devices no further than 3 feet
- 3. Ensure Bluetooth is enabled on your device. Refer to the manufacturer's instructions for how to enable Bluetooth on vour device.
- 4. Press the On/Off switch and the device will automatically search for your device indicated by a beep.
- 5. Once you have activated Bluetooth on your device, select the speaker "BMHLEDSPKR" from the list of available Bluetooth
- 6. If required, enter the PIN code "0000" and confirm the

Note: If pairing is unsuccessful, turn off the speaker first and re-pair following the mentioned steps. Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

OPERATING THE SPEAKER

Once the speaker is paired to your device, you can stream music wirelessly to the built-in speakers.

ADJUST LIGHTS

Short hold for led flashing lights, Short hold for no lights.

ADJUST VOICE VOLUME

Short hold the volume switch "-" for previous song, and long hold for volume decrease.

Short hold the volume switch "+" for next song, and long hold for volume increase.

FM FUNCTION

Short press the M button, plug in the charging cable to search

In the FM radio state, the on/off key is for automatic station search, the + button is for the next station, the - button is for the last station.

SPECIFICATIONS

Bluetooth® Version: V5.4 5W x 2 Speaker Output:

Frequency Range: 2400MHz-2483MHz

90 dB Sensitivity: Play Time: 5-6 Hours Battery Type: Li-lon Battery Capacity: 1200 mAh DC 5V Charging Voltage: About 2 Hours Charaina Time: Charging Interface: Micro USB

CARE AND MAINTENANCE

- Do not expose the unit to excessive heat or humidity to avoid damage to the product's internal circuitry.
- Do not use abrasive cleaning solvents to clean the unit.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- Do not dispose of the unit in fire as they may explode or combust.
- Do not expose the unit to contact with sharp objects as this will cause scratches and damage.
- Do not let the unit fall from high places, as doing so may damage the internal circuitry.
- Do not attempt to disassemble the unit.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the

party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

DGL Group, Ltd. 2045 Lincoln Highway Edison, NJ 08817.USA