

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation, changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected,
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

Lenovo Watch S

Pedometer

The watch monitors pedometer automatically, short press once the second hand indicate the current movement completeness.


Declaration: Set in app before use.

Remote Shutter

Enter into app photo interface.Press the button of watch to remote control phone


Sleeping Monitor

Monitor sleep Automatically and check sleep data via app.



Smart Time Sync

When the APP enters the calibration interface, the watch stops moving and input the position of the watch pointer into the APP. When the calibration starts, the watch pointer will synchronize with the time of the mobile phone system.



运动计步

手表自动监测运动计步，短按1次按键，秒针自动指示当前运动完成度。

说明：使用时，在APP中设置运动目标。

遥控拍照

进入APP拍照界面，短按按键或者拖动手表，触发手机拍照。


睡眠监测

手表自动监测睡眠，在APP查看睡眠数据。




智能校时

APP进入校时界面，手表停止走针，将手表指针所指位置输入到APP中开始校时，手表指针将会和手机系统时间同步。



OTA Upgrade

It will remind you update automatically once app updated with new version. Declaration: There will be a little possibility to update failure du to special difference between cellphone, But you can try again if upgrade fail.




Change Battery

Use professional tool to open the back cover of watch. Take out the old battery and put new battery into the battery jar.Click the reset button on the back. Turn on to make sure the battery is installed in place.Then close the cover with the tool and start to use the watch, PS:suggest to change battery in specialized watch repair shop, Battery model No.CR2032.

Low battery alert

After entering low power state, Watch will turn off the bluetooth and intelligent function automatically and only pointer walking,then you should change battery.Declare: Now long press the button for 3 seconds, the light flases once won't turn on bluetooth.



空中升级

手表固件有新版本更新时，进入APP时会自动提示，点击更新后，自动升级。

说明：由于不同型号手机可能存在差异性，会存在较小概率的升级失败。升级失败后，可以重新尝试升级。



更换电池


用专业工具将手表后盖打开，取出旧电池，将新电池放入电池槽内。点击背面复位孔按键，恢复出厂设置。开机确认电池已经安装到位，然后用专业工具合起表盖，开始使用手表。

备注：建议到专业修表店更换电池，电池型号为CR2032。


低电提醒

进入低电状态后，手表将自动关闭蓝牙和智能功能，只进行走时，需要更换电池。

说明：此时长按按键3秒，会闪灯1次，不会开启蓝牙。




Dialplate description



Material


Shell case : zinc-alloy (sand blast)
Bottom cap: Stainless steel
Glass: Blue diamond glass
Watch band: silicon band



Size&configuration


Diameter: 40mm
Thickness: 11mm
Width: 20mm
Net weight: 52g
Waterproof: 50metres

表盘图标说明



材质

表壳: 锌合金 (磨砂)
底盖: 316L不锈钢
镜面: 蓝宝石玻璃
表带: 硅胶



尺寸&配置

直径: 40mm
厚度: 11mm
表耳宽度: 20mm
净重: 52g
防水: 50米

Turn on

Long press the button for 3 seconds, and the 12 o'clock position light flicker continuously.

Open the bluetooth


Long press the button for 3 seconds to open bluetooth, the 12 o'clock position light flicker continuously.

Connect Bluetooth

enter the APP bluetooth search interface and choose the bluetooth name to connect, the watch will vibrate during th connection.Meanwhile press the button or shake the watch to confirm the connection, then the APP will skip to the function page.

Close the Bluetooth

Press the button for 3 seconds, to turn off thebluetooth, and the 12 o'clock position light flashes once.



Check bluetooth


Short press the button, If the 12 o'clock position light flashes continuously, the bluetooth is not connected, If the 12 o'clock position light is on for 2 seconds, the bluetooth connected; If the 12 o'clock position light flashes once, bluetooth close.

Looking for cellphone

Short press the button twice continually (the time interval is 0.5-1 second),Turn on the finding phone function.The watch will vibrate once while the phone ringing.

Recover original factory mode

Long press the button for 12 seconds , enter power off status and recover factory setting.



开机

长按按键3秒，12点位置灯快速闪烁，开机时，同时蓝牙打开。

开蓝牙

长按按键3秒，开蓝牙，12点位置灯连续闪烁。

连接蓝牙

进入APP蓝牙搜索界面，点击蓝牙名连接。连接过程中，手表会震动，此时按键或拖动手表进行确认连接，APP跳转至功能页面。

关蓝牙

长按按键3秒，关蓝牙，12点位置灯闪1次。



查看蓝牙

短按按键，看12点位置灯连续闪，则蓝牙未连接，若12点位置灯闪亮2秒，则蓝牙已连接，若12点位置灯闪一次，则蓝牙已关闭。

查找手机

连续短按2次按键（时间间隔为0.5-10秒），手表会震动1次，开启查找手机功能，手机便会响铃。

恢复出厂模式

长按按键12秒，进入关机状态并恢复出厂设置。



In order to meet the laws, regulations and other requirements related to the restriction of hazardous substances in China's electronic and electrical products, lenovo shall classify the hazardous substances in this product according to the parts, and declare as follows.

Part name	Harmful substances					
	Pb	Hg	Cd	Cr (Vr)	PBB	PBDE
Printed circuit board components	X	O	O	O	O	O
Enclosure and accessories	X	O	O	O	O	O
	<p>This form is prepared in accordance with SJ/T 11364, O Means that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572. X: Means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.</p> <p>The parts marked "X" in the table.Because of the limitation of global technological development level, it is impossible to replace harmful substances PCB components *: including PCB and its parts, electronic components, etc, Depending on the model, the product you purchased may not contain all of the above components.</p>					
	<p>Electronic and electrical products sold within the territory of the People's Republic of China shall bear this mark, and the number in the mark shall represent the environmental protection term of the products, under normal use</p>					

Call Alert

Authorize and turn on call alerts function in app before using. Watch vibrates to alert you of incoming call. Short press the button of watch or shake it to reject an incoming call.

Sedentary Alert


Setting sedentary function in APP. Watch vibrates to alert you of being sedentary for too long.

Message Alert

Authorize APP alerts before use app message reminder. Watch vibrates when message is coming.

Silent Alarm

Turn on the APP to set the alarm, and the alarm Settings will be saved into the watch automatically, watch will vibrate at the right time.



来电提醒

使用前请打开APP中来电提醒开关，在手机系统中授予APP提醒权限。电话来时，手表震动。短按按键或拖动手表，挂断电话。

久坐提醒

使用前打开APP设置久坐提醒功能，久坐提醒时间到，手表会震动。

应用消息提醒

使用前打开应用消息提醒，在手机授予APP提醒权限。消息来时，手表会震动。

闹钟提醒

使用前打开APP设置闹钟，闹钟设置会自动保存到手表中，手表到时间会震动。

