

## 材质:156g铜版纸,三折页。





3. Setup and Use

Timer Setup

M1 Mode Lock Settings

5 Power interface


4 Child lock button

Side

**Note:** You need to reset the password, every time you switch the toggle back to M2.

(Use this method to reset your password if you have forgotten it.)

① Press 🔞 to select minutes, hours, or days from right to left; 2 Press  $\land$  or  $\lor$  to set the selected time (hold for rapid setting); ③ After setting the time, press 📵 ; this begins the locking countdown, and locking completes after the countdown ends; 4 During the countdown, any button may be pressed to cancel the lock; ① Press and hold ⑩ button for 5 seconds while in the locked state to increase the lock duration; 2 Press button to select minutes, hours, and days from right to left for setting; 3 Press  $\wedge$  or  $\vee$  to set the currently selected time (long press to quickly set); 4) After setting the time, press to save the additional time immediately; You can only make the lock time longer with this option. If you try to set a time shorter than what's already left, it won't save your changes. M2 Mode Lock Settings 1) Password Setting: ① Switch to M2 mode by toggling the  $\bigcap_{M2}^{M1}$  , then enter password setting mode; 2 Press to switch digit positions; 4 Press  $\ \textcircled{\ \ }$  to confirm and save the password; 2) Locking: After setting the password, hold the for 3s to lock immediately. 3) Change password: ① In unlocked state, toggle  $\bigcirc_{-M2}^{-M1}$  switch to reconfigure password parameters.  $\ensuremath{\mathfrak{D}}$  After emergency unlocking your locked device, reset your password using  $\ensuremath{\mathfrak{D}}$  in Unlocking ① Automatic Unlocking: In M1 mode, automatically unlock when the timer ends; 2 Password Unlocking: In M2 mode, press 📵 to enter password input mode, press 🔞 to switch digit



## **FCC Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

## RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.