55mm



80mm



产品示意图

包装清单

①智能眼镜眼镜

②充电线

③说明书

XG88 Pro

产品规格

产品型号: XG88 Pro开放式定向音频眼镜 无线版本: V5.3 充电时间: 约60分钟 电池容量: 80mAh 传输距离: ≥10米

镜片材质: PC 充电电压和电流: DC 5V 待机时间: 120小时

蓝牙协议: A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP/SPP/HID 声道: 双声道,立体声

功能操作说明

长按 暂停/播放键 3s开机,提示"Power on/开机"红蓝灯交替闪烁

(2) 关机 长按 暂停/播放键 5s关机,提示 "Power off/关机" 熄灯

单击 暂停/播放键 (4) 切换歌曲

双击上一曲键: 上一曲; 双击下一曲键: 下一曲 三击 上一曲键: 音量-; 三击下曲键: 音量+

(6)接听电话

单击暂停/播放键,提示来电报号+嘟......

(7) 拒接来电 长按 暂停/播放键 2s (8) 挂断通话 单击新停/播放键

当电池电量低于 3.2V 时,低电量提示音 30s循环一次, 电量低于 3.0V 时低电关机,提示"滴嘟"红灯5秒闪一次

长按 暂停/播放键 1.5s松手唤醒 Siri 功能

配对方式

(9) Siri 语音功能

(1) 手机配对 打开手机蓝牙, 扫描新设备, 找到 "XG88 Pro "点击配对即可,

(2) 手机配对成功

设备显示连接成功,提示 "connected/连接成功"

配对模式下超过5Min 未与手机进行配对, 耳机自动关机, 红蓝灯交替闪烁

(4) 断开连接 手机主动与耳机断开连接,提示 "disconnected/连接断开"

红蓝灯交替闪烁

手机蓝牙打开状态下, 耳机开机后会自动回连上次已配对过的

充电操作

(1) 耳机充电 输入 DC:5V 电源充电,红灯常亮 (2) 耳机满电

注意事项

1. 使用产品前请仔细阅读本使用说明书并请妥善保管

首次使用,请先将本产品充满电
 如果产品长期(超过1个月)不用,请对其充电

4. 若手机无法搜索蓝牙耳机,请确认蓝牙耳机是否处于"配对 状态",若长时间未进行配对或连接,蓝牙耳机配对功能将关闭。请重新开启蓝牙耳机至"配对状态":若手机程序出错。 请重启手机;若蓝牙耳机程序出错,请重启蓝牙耳机

1. 请勿以任何理由拆除或维修改装耳机,否则可能会导致起火 电子元件击穿甚至彻底损坏本产品

2. 请勿将设备置于温度过低或过高(0℃以下或 45℃以上)的

3. 请避免靠近儿童或动物的眼睛使用设备指示灯

4. 请勿在雷暴天气下使用该设备,雷暴可导致设备工作不正常 并偿加触由的危险

5. 请勿用油及其他挥发液体擦拭本产品


6. 请勿将设备接触液体弄湿

Smart glasses User manual



XG88 Pro

Product diagram





packing list

Smart glasses and glasses
 Charging cable
 Instruction manual

Product specifications

Product model: XG88 Pro open directional audio glasses Wireless version: V5.3

Charging time: approximately 60 minutes Battery capacity: 80mAh

Transmission distance: ≥ 10 meters Lens material: PC

Channel: Dual channel. Stereo

Functional operation instructions

Long press the pause/play button for 3 seconds to turn on the device, and the red and blue lights will flash alternately when prompted with

Press and hold the pause/play button for 5 seconds to shut down.

Press and hold the pause/play button for 5 seconds to shut down, and the prompt" Power off Shutdown" will turn off the light (3) PlayPause (Click tyP pause/play button (4) Switch songs Double click on the previous track button: Previous track; Double click on the next track button: Next track

. Three clicks on the previous key: Volume -; Three click down key:

volume+
(6) Answer phone calls
Click the pause/play button, prompt for incoming call number+beep

(7) Reject incoming calls (7) Reject incoming calls Long press the pause/play button for 2 seconds (8) Hang up the call Click the pause/play button

Charging voltage and current: DC5V
Standby time: 120 hours
Bluetooth protocol: A2DP/AVDTP/AVRCP/RFCOMMHFP/

Pairing method

(1) Phone pairing Open your phone's Bluetooth, scan for a new device, find "XG88 Pro", and click on pairing, The red and blue lights flicker alternately.

(9) Siri voice function Long press the pause/play button for 1.5 seconds to release and wake up the Siri function

wake up the SIT function (10) Low battery warning when the battery level is below 3.2V, the low battery warning sound will cycle once every 30 seconds, When the battery level is below 3.0V, the device will shut down due to low power, and the red light huill flash once every 5 seconds,

The feet and to the upins theker atternatery.

(2) Phone pairing successful
The device displays a successful connection and prompts
"connected" (3) Pairing time
In pairing mode, if the phone is not paired for more than 5 minutes,
In pairing mode, if the phone is not paired for more than 5 minutes, the headphones will automatically shut down

the heappnones will automatically shut down, Flashing red and blue lights alternately (4). Disconnect The phone actively disconnects from the headphones and prompts "disconnected" disconnected" 'Elashing red and blue lights alternately

(5) Automatic reconnection
When the Bluetooth of the phone is turned on, the earphones will

when the Buccount of the priorie is turned on, the early mones with automatically reconnect to the last paired pair after being turned on Device, prompt "connected/successfully connected"

Charging Operation

(1) Earphone charging Input DC: 5V power supply for charging, red light always on (2) Earphones fully charged

pay attention to

Before using the product, please read this user manual carefully and keep it properly
 For first use, please fully charge this product first
 If the product is not used for a long time (more than 1 month),

3. If the product is not used an for a long time (more than 1 month) please charge it. I please charge it. I please charge it is the production of the pr the Bluetooth earphone program, please restart the Bluetooth

warning

1. Do not dismantle, repair or modify headphones for any reason, otherwise it may cause electronic components to break down or even completely damage this product due to fire. 2. Do not place the device in an environment where the temperature is too low or too high (below 0 ° C or above 45 ° C). Please avoid using device indicator lights near the eyes of children.

or animals

4. Do not use this device in thunderstorm weather, as thunderstorms can cause the device to malfunction and increase the risk of electric

shock 5. Do not wipe this product with oil or other volatile liquids

6. Do not wet the device when it comes into contact with liquid

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.