

**LYTMI COZYFIT G1**  
THE MOST COMFORTABLE EARBUDS WITH ANC  
**USER MANUAL**

Diagram illustrating the components of the charging case and earbuds:

- Touch Area
- Charging Pins
- Charging Case Indicator
- Type-C Charging Port
- Reset Button
- Charging Contacts

Pick up the earbuds from the charging case, then rotate the earbuds **along your ear's curve** to achieve the proper fit.

Open the charging case. The earbuds will automatically power on and enter Bluetooth pairing mode when connecting for the first time. Select 'Lytmi CozyFit G1' from your device's Bluetooth list. For subsequent use, simply open the charging case, and the earbuds will automatically reconnect.

- To power off, return the earbuds to the charging case and close it.
- The earbuds will automatically power off after 5 minutes if they are not connected.

Remember to tear off the protective films on the earbuds before first use.

1. Place the earbuds in the charging case and close it. Fully dry off the earbuds and the USB-C charging port before charging.
2. Connect the charging case to a power supply by using a certified USB-C charging cable.

You will hear a du du tone when the battery is running low.

Download the 'Lytmi Connect' app to adjust EQ settings and explore more features. If your earbuds cannot connect with the Lytmi Connect app, try reinstalling or updating the app to the latest version from your mobile app store.




1. Open the application program.
2. Check and agree to the "login agree tip".
3. Click "Add Device".
4. If the application prompts "please open blue-tooth", please go to the phone settings to ensure that Bluetooth is turned on and connected. (Note: If there is no such prompt, ignore this step.)
5. Return to the device search page of the app and select the product that needs to be connected.
6. The connection is successful.

Note: For a better product experience, you can promptly go to "Mine" to register an account and log in to avoid the loss of relevant personalized settings.

Note: The UI images are for illustrative purposes only. Actual display content may vary depending on the software version.

Tap 'Button Settings' on the homepage to personalize button control actions for either the left or right earbud. You can adjust actions such as increasing/decreasing volume, switching songs, playing/pausing audio.



	Answer / End a call	Double tap
L/R	Reject a Call	Touch and hold for 2 seconds
	Play / Pause	Double tap
	Cancel a Call	Double tap
	Exit Voice Assistant	Single tap
L	Open Voice Assistant	Touch and hold for 3 seconds
	Previous Track	Triple tap
R	Next Track	Triple tap
	Music / Focus Mode	Touch and hold for 3 seconds

When the phone fails to search for the headphone name for pairing, please follow these steps: Place both earphones into the charging case and open the lid. Then, press and hold the button on the charging case for 3 seconds. In this way, both earphones will enter the pairing state simultaneously.

Reset if the earbuds have issues pairing with each other or with other devices.

Place both earbuds in the charging case and open the lid. Press and hold the charging case button for 8 seconds to restore factory settings. The case indicator will blink green once per second (8 times total).



Brand	Lytmi
Model	Lytmi CozyClip G1
BT Version	BT 5.2
Charging Input	5V=0.5A
Battery Capacity	55mAh (Earbuds) 380mAh (Charging Case)
Charging Time	1.5 Hours (Earbuds) 1.5 Hours (Charging Case)
Waterproof Rating	IPX4 (Earbuds)
Bluetooth Range	10 m / 33 ft

1. Do not charge the charging case continuously for more than 12 hours.
2. Do not disassemble the headset or put the device into the fire to avoid explosion.
3. Do not place the magnetic charging cable or the magnetic charging port or the headset near metal objects.
4. Use of charging cables not approved by the manufacturer may cause fire, explosion or other hazards.
5. Use the product within the temperature range of 32°-95°F and store the product within the temperature range of 14°F-113°F. Excessively high or low temperatures may cause equipment malfunction.
6. Do not expose the headset to the sun for a long period of time, otherwise it will be easily deformed.

7. This product has a built-in non-removable lithium battery, the battery is prohibited from disassembly, impact, extrusion or put into the fire, if there is a serious expansion, please do not continue to use.

- Warranty: 12-Month Limited Warranty
- Support: Lifetime Technical Support
- Email: [support@lytmi.co](mailto:support@lytmi.co)
- Official Website: [www.lytmi.co](http://www.lytmi.co)
- Support Phone: (+1) 2108588666
- [youtube@lytmi](https://www.youtube.com/lytmi)
- [Instagram@lytmiofficial](https://www.instagram.com/lytmiofficial)
- [Facebook@lytmi](https://www.facebook.com/lytmi)
- [Tiktok@lytmi](https://www.tiktok.com/lytmi)

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.