Control Method:

Adopt RF remoter to control the LED controller, which has 21 buttons, the function of each button as the table below:

ON	Jump	OFF	Juny (I)
Fade	Flash white	Chase	Face Eath Chate
8 COLOUR	8 COLOUR	8 COLOUR	
STEADY	FADE	FLASH	Steedy Fade Plash
ONE COLOUR	ONE COLOUR	ONE COLOUR	
FLASH OUT	CHASE	WAVE	Flash Chase Wave
ONE COLOUR	ONE COLOUR	ONE COLOUR	AAA
Static red	Static Green	Static blude	
Static yellow	Static purple	Static cyan	
Static white	Random colour	Auto change	

- 1. "ON" "OFF", control power on or power off.
- 2. Buttons in pink cyan, "JUMP" "FADE" "FLASH WHITE" "CHASE", can auto change different colour for different effect.

3.Buttons in pink area, "STEADY""FADE""FLASH WHITE""FLASH OUT""CHASE" "WAVE" are function keys, the other keys are colour keys. Please select function key first, then color key.

4. "AUTO" can auto change different effects.

FCC ID: 2AVBD-RF01

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.