

Please scan to download the full version of user manual Bitte scannen Sie es, um das Handbuch herunterzuladen Veuillez scanner pour obtenir le manuel complet Zeskanuj poniższy kod QR, aby uzyskać instrukcję obsługi onlin



CONTENTS VERZEICHNIS CONTENU SPIS TREŚCI

1. W	hat's in the box?	- 1
W	as ist in der Box?	25
Q	u'y a-t-il dans la boîte? !	51
С	o znajdziemy w pudełku?	77

2.0	Camera Overview	2
S	31 Pro Kameraübersicht2	26
V	/ue d'ensemble de la caméra 5	52
E	Budowa ka me r7	8

Installation	5
Installation	30
Installation	56
Instalacja	

4.	Basic Operation 9
	Grundlegende Bedienung33
	Opération de base59
	Podstawowe_funkcje 48

5. Warrning 22	5. Warrning	 22
Warnung 47	Warnung	 47
Précautions73	Précautions	 73
Ostrzeżenia 99	Ostrzeżenia	 99

6. Warranty & Support 23
Garantie und Suppor 49
Garantie & Suppor 75
Gwarancja & wsparcie101

1. What's in the box?





A. Vantrue S1 Pro B. Rear Camera Dash Cam



E. Rear Camera Cable (20ft)



]:]

MANTHUE

C. GPS Mount



D. Car Charger with Built-in Type-C Cable (11.5ft)

VANTRUE	

- G. Electrostatic H. Crowbar Stickers*2









- I. Dust-free Cloth J. Warning Stickers *2
- K. 3M Adhesive L. Quick User Guide Stickers*2

Optional Accessory





M. CPI Filter

N. Wireless Remote Control

2. Camera Overview



- 1.2 inch IPS Screen
- 2. Front-Facing Camera
- 3. Type-C USB Port for Rear Camera
- 4. Reset Button
- 5. MicroSD Card Slot

- 6. Type-C USB Port for Charging
- 7. Microphone
- 8. Type C USB Port for Rear Camera Cable
- 9. Rear Camera
- 10. Rear Camera Indicator Light

Button Instruction



No. Buttons Instruction

- 1. A In menu settings and file browsing, short press to display the previous option, long press to scroll up to display options; In playback mode, short press to fast forward;
- □ During video recording, short press to start/stop recording;
 □ In menu settings, short press to confirm the action; In playback mode, short press to play/pause the file;
- 3. ✓ During video recording, long press to turn on/off WiFi, and
 ♦ ·
 ♦ ·
 ♦ in the short press to turn on/off the microphone; In menu settings and file browsing, short press to display the next option, and long press to scroll down to display options; In playback mode, short press to pop up the delete file menu;
- 5.
- In power-on status, long press to turn off the dash cam; In power-of status, short press to turn on the dash cam; During video recording, short press to capture a picture; In playback mode, short press to pop up the delete Menu.



3. Installation

3.1 Installing a Memory Card (Recommend Vantrue U3 high-speed microSD card).

Please insert a memory card (memory card capacity: 32GB-512GB, card speed: U3/Class10/A2, recommend Vantrue U3 microSD card) into the card slot according to the direction indicated in below picture, until a "click" sound is heard in the card slot, indicating that the memory card is inserted properly.



After inserting the memory card, if the screen prompts "Card error, please format", please directly press the \equiv button to enter the menu, then go to 'system setup' and choose 'format' to start the formatting process.

- The microSD card should be formatted once a month to maximize the lifetime of the memory card.
- Please do not take the card out when the camera is recording in case the important video file missing.

3.2 Installing the Mount

Align the mount with the dash cam mount interface then push in until the mount is installed



3.3 Mounting the Front Camera

Thoroughly clean the windshield with water or alcohol, then wipe it with a dry cloth. Remove the protective film from No.1, stick the electrostatic sticker next to the rear-view mirror, which is the recommended position to prevent blocking your view while driving. Then remove the protective film from No.2 and the mount, fix the mount and camera on the electrostatics stickers.



3.4 Running the rear camera connecting cable to the rear of the vehicle

Plug the rear camera connecting cable into the front unit, run the cable along the headliner, and straight down the length of the car to the A, B, and C pillars.



3.5 Mounting the rear camera

When installing the rear lens, please avoid the defogging line on the rear windshield, so as not to affect the video effect. Remove the protection film of the sticky pad and rear camera lens. Fix the rear camera in the selected position and adjust the angle. (The rear camera can rotate 360°, if the installation is wrong, you can turn on rotate display to adjust.)



3.6 Installing the Car Charger

Insert one end of the car charger to the car cigarette lighter and the other end to the Type C port on the front camera mount, start the ignition, waiting for the dash cam to start.



Basic Operation 4

4.1 APP Download

Please scan the OR code for the relevant version below to download the APP EN and install it.



4.2 WiFi Connection

The WiFi will be turned on automatically when S1 PRO dash cam is turned on. If WiFi is turned off, you can reopen the WiFi through shortcut keys, voice control. or menus.

After turning on the WiFi function of the camera, please click "+" to find "S1 PRO" in the "Sonnet Series" through Vantrue APP, choose the right dash cam to connect, then the app will automatically connect to the camera and display the current real-time recording situation of the camera.



Note:

- Before connecting WiFi, please make sure the WiFi function of your smartphone is enabled.
- The initial password for this device is only used for initial login. In order to prevent potential security risks, please be sure to change the initial password after the initial login to prevent others from logging into your device without authorization or other adverse consequences.
- If you forget the WiFi password, you can restore the default setting of the device, and the Wi-Fi password of the device will also be restored to the default password(12345678).

4.3 APP Connection



After the app is successfully connected to the camera, you can perform the following operations:

- 1. **Video preview:** In the real-time preview interface, you can switch to the full-screen preview mode by clicking the full-screen icon or placing the phone horizontally, click the window switch icon to switch video windows, only multi-channel recording can use this feature.
- 2. **Video playback:** The video and photo files recorded on the SD card can be viewed in the app, and the video can be played back after clicking the file.
- 3. Video download: You can select the video or picture you want to download in the SD card browsing interface or in the video playback area. After downloading the video, if you play it in the local file of the app interface, you can view the GPS track of the video.
- 4. Video snapshot: You can capture the current screen in the real-time

preview interface of the app.

- 5. **Mileage statistics:** You can click to download mileage information as required, and the mileage information will be saved in the APP as a picture or PDF file.
- 6. Lens correction line: Correct the lens balance via accurate crosshair so that the video screen will not be skewed.
- 7. **OTA upgrade:** You can upgrade the S1 PRO dash cam via APP, please refer to 4.12 for more details.
- 8. **Real-time video resolution switching:** You can switch display resolution in the real-time preview interface by clicking the (AUTO) icon.

4.4 APP Upgrade

Open the "Vantrue" APP, connect to Wi-Fi, enter "Settings> About> Detect New Version". The App will automatically detect whether its version is the latest version. If there is a new version of the app, follow the prompts and upgrade the version.



4.5 Loop Recording

After inserting the memory card and connecting the power, the dash cam will automatically turn on and enter loop recording. The duration of each recorded video will be saved based on the loop recording time you set, saved in the normal video older. When the capacity of the normal video folder reaches 70% of the total capacity, the new loop recording file will automatically overwrite the original loop recording files.



- When Loop Recording is turned off, the video lock function will no longer work.
- After the loop recording is turned off, the duration of each video will be 20 mins, and the recording will stop when the memory card capacity is full.

4.6 Event Recording

Event video is triggered by the G-sensor (Gravity Sensor), which can be automatically triggered or manually locked. During driving, in case of special circumstances, the camera will automatically lock for event recording or you can manually lock the event recording into the event folder (photo will be saved in the photo folder) by pressing the button. During the lock video period, you can press the button to capture multiple times.



- The sensitivity of the automatic locking video trigger is determined by the sensitivity of the collision. The higher the sensitivity setting, the greater the probability of being triggered.
- The total capacity of the event video file accounts for 30% of the total capacity of the current memory card. When the event video file reaches the upper limit, the new event video file will automatically overwrite the old event video file. It is recommended to periodically check and save your event video files to avoid loss.
- Lock recording will not trigger in either of the following situations: Loop recording is off or Time lapse recording is on. You can only capture photos with loop recording off/ time lapse on.

4.7 Parking Mode (Constant Power Supply Needed)

Parking Mode operates as a sentry function under different situations. Please go to "Record Setup" > "Parking Mode", press ∨ button and select the following options: Collision Detection, Motion Detection, Low Bitrate Mode, Low Framerate Mode, OFF.



After the parking mode is turned on, there are three ways to record:

- 1. You can wait for 5 minutes to start automatically.
- 2. long press the \equiv button to begin manually.
- 3. Install the Vantrue ACC hardwire kit and the dash cam will directly enter after the car is stopped the engine (the ACC hardwire kit needs to buy separately).

- To ensure the camera is able to function in Parking Mode, please keep it powered with a mobile power bank or hardwire it directly to the car battery.
- When the temperature in the car is as high as 60°C(140°F), it is recommended that you turn off the camera to avoid abnormal operation of the camera caused by the high temperature.

Collision Detection

When collision detection is enabled, the icon will be displayed on the recording interface. If no movement is detected after 5 minutes of recording, collision detection will be activated with the icon in the center of the screen, and the camera automatically turns off. It will start to record for 1 minute after being shaken, then turn off the dash cam again. If the dash cam continues to be hit during the collision detection recording, it will exit the collision detection mode and enter normal recording, restarting the 5-minute entry mechanism. Collision detection sensitivity can be adjusted from 1 to 5 levels. You can adjust according to your habits, as well as the surroundings of the car.



Collision Detection Icon

Motion Detection

When the motion detection is turned on, the silicon will be displayed on the recording interface. If no movement is detected after 5 minutes of recording, the motion detection will be activated with an orange silicon in the center of the screen, and the screen will turn off after 3 minutes. When the camera detects object movement, it will automatically trigger video recording for 30 seconds. After the motion detection recording ends, the camera will load a 15s pre-recorded video into the 30s motion detection video and save the 45s video to the normal folder.



Motion Detection Icon

The motion detection range of the front and rear areas can be adjusted respectively, and the set range can be adjusted up and down, left and right. Please go to "Motion detection Area" on the "Record Setup" to set the area range. You can select 1X, 2X, 3X, 4X, or 5X range. The 5X range is the global detection mode.



4.8 Parking Collision Detection

After turning on the parking Collision detection mode, you can select the power saving mode or the quick start mode. In the power saving mode, after entering Collision detection, the dash cam will be turned off, and after the collision is triggered, it will be turned on for recording; In the quick start mode, after entering Collision detection, the dashcam screen will be turned off and the recording will be stopped, and the recording will start immediately after the collision is triggered.

4.9 Voice Assistant

You can also control the camera with voice command, such as take photo, video start, turn on/off WiFi, lock the video, etc. Currently supported languages are English, Japanese, Russian, and Chinese. Voice recognition has options such as low sensitivity/ standard/high sensitivity/off. The default setting is standard sensitivity. For more detailed voice commands, please check System Settings > Voice Content.



Voice Assistant Icon

- 19 -

4.10 GPS Function

GPS is enabled by default, it can automatically calibrate the time and date in your area, recording the location where the video was taken and the speed of the car at the time. To view it, please download and install the Vantrue APP and VANTRUE GPS Player (available for download at www.vantrue.net).



1. Connect the included TYPE-C USB data cable to the camera and the computer.





2. After the connection is successful, the display of the camera to transfer data, and then you can view and delete the video files in the computer folder.



4.12 Upgrading Firmware(Please keep it plug in when upgrading)

Option 1: Upgrade via PC

After downloading the latest S1 PRO firmware via Vantrue Official Website, place the file into the root directory of the memory card, insert it back into the dash cam, power on to upgrade.



Option 2: OTA(OvertheAir) Firmware Update

After opening the APP, you will receive the firmware update push. Once confirming the upgrade, it will jump to the OTA upgrade interface, which can be upgraded according to the APP guidance.

Please note: OTA requires network traffic to download upgrade files.







5. Warning

- This product is an auxiliary device for the purpose of recording exterior images of vehicles, and some functions may not be supported due to different driving and vehicle environments.
- Firmware upgrade will be carried out from time to time to further improve the product, please pay attention to the official notice of VANTRUE according to the specific upgrade.
- This product can record and save images of vehicle accidents, but it does not guarantee that all accident images can be recorded. The image may not be recorded in a special folder because the crash sensor cannot be activated for minor crashes.
- Be sure to turn off the power when inserting or removing the memory card.
- For stable use of the product, please format the memory card at least once a month.
- Generally, memory cards have a life span, and long-term use of memory cards may result in data not being saved. In this case, it is recommended to purchase a new memory card for use. If the data is destroyed due to the long-term use of the memory card, the company will not be held responsible.
- Do not install or operate this product while the vehicle is running.
- Do not subject the product to strong shocks or vibrations, which may damage the product and cause malfunction or inoperability.
- Do not use chemical solvents or cleaning agents to clean the product.
- The ambient temperature range for normal use of this device is -20 degrees Celsius to 60 degrees Celsius. Exceeding this ambient tempera ture range may cause the product to malfunction.
- Do not place the product in an open flame. Do not use the product in high temperature and high humidity areas, as this may cause electric shock, short circuit, and other hazards and damage the product.

- It is forbidden to disassemble or modify the car charger by yourself, or use a short-circuit car charger, otherwise it will cause personal injury, electricshock, fire and other dangers or damage the product.
- Please do not disassemble or modify the product without permission to avoid damaging the recorder, generating heat and causing fire.
- Please use this product within the scope of the law.

6. Warranty & Support

Warranty

The VANTRUE® S1 PRO Dash Cam comes with a full 12 months warranty. If you register your product on our official site (www.vantrue.net/register), you can extend the warranty to 18 months.

Support

If you have any questions regarding your product, please solve it in the following ways: 1. Open Vantrue APP, find the solutions in the frequently asked questions; 2. Contact customer service of your purchased channel; 3. Drops us an email at support@vantrue.net. Queries are typically answered within 12-24 hours.

Your opinion matters

VANTRUE® is firmly committed to always improving our products, services, and user experience. If you have any thoughts on how we can do even better, we welcome your constructive feedback and suggestions.

If you need the full version of user manual, please download on our official site, or connect with us today at support@vantrue.net.

Hey, find us here:



VANTRUE

www.vantrue.net/contact



facebook.com/vantrue.live

Thank You for choosing Vantrue

PMN: 2 Channel Voice Controlled Smart Dash Cam

FCC Warning This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FOC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and , if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1) Reorient or relocate the receiving antenna.

2) Increase the separation between the equipment and receiver.

3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

4) Consult the dealer or an experienced radio/TV technician for help

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This equipment complies with FOC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

I SED St at ement

- English: This device complies with Industry Canada license- exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

- French: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradi oélectriquesubi, mêmesi le brouillagest susceptible d'encompromettre le fonctionnement. l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

L'appareil destiné à fonctionner dans la bande 5150-5250 MHz est uniquement destiné à une utilisation en intérieur afin de réduire le potentiel d'interférences nuisibles aux systèmes mobiles par satellite cocanaux.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.