

Function	Operation
Power on	Take out the earbuds from the charging case and long touch Multi Function Button (MFB) 2s
Power off	Put the earbuds into the charging case or long touch Multi Function Button (MFB) 5s
Pairing Mode	LED light flashing red & blue at first.
Connected	Blue LED light flash slowly.
Charging case charging	Red LED light flash
Charging case fully charged	Red LED light is on
Earbuds charging	Red LED lights of earbuds are on
Earbuds fully charged	Red LED lights of earbuds turn off automatically
Play/Pause	Single touch Multi Function Button (MFB)
Picking up incoming call	Single touch Multi Function Button (MFB)
End phone call	Single touch Multi Function Button (MFB)
Reject incoming call	Long touch Multi Function Button (MFB) 2s
Skip to next track	Double touch Multi Function Button (MFB) of the right earbud
Start over current track/ Skip to previous track	Double touch Multi Function Button (MFB) of the left earbud
Volume up	Triple touch Multi Function Button (MFB) of the right earbud
Volume down	Triple touch Multi Function Button (MFB) of the left earbud

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Mules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that Interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment df and on, the user is encouraged to try to correct the interference by one or more of the following measures: — Receint or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the
- receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

FCC ID: 2ATF51604783 Model: EBT1-21044