

### Notice for TWS Connection

If you have two pieces BoomPro, you can use TWS to achieve wireless stereo combined playing music.

Note: Before TWS pairing, make sure the two BoomPro speakers are not connected over bluetooth.

1. Press  $\odot$  for 2 seconds to power on both speakers.

 After you turn on the device, you should make sure neither are connected to any bluetooth since both will automatically reconnect to your previous device. So you should disconnect existing device first or just turn off bluetooth on your devices.

 Press ⋈ once on either speaker, a beep will be heared once TWS is connected.

4.Then make connection with mobile phone.

# Important Notice for Charging

- Before charging, be sure the speakr is at room temperature, between 46° F (8° C) and 102° F (39° C).

- Use this product only with an agency approved power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC) which support 5V / 2A.


- Use inlcuded charging cable to charge the speaker.

- For the first use, please fully charge the product.

 Connect the type C end of the included charging cable to the charging port on your speaker. Then plug the other end of the USB charging cable into a suitable USB port on your computer (or with a standard cell phone charger) to recharge your speaker's internal rechargeable battery.

2. You should charge the speaker when hearing low battery prompt voice. Speaker will power off automatically after

#### Care and Maintance



collected separately. Collection systems and locations (sorting centres, rubbish dumps) are provided for you by local councils and retailers. By entrusting your end-of-life product to the proper recycling process, you are helping to protect the environment and your health.

3. Use this device in temperate climates only.

4. Use the apparatus in moderate climate only.

5. This device may be used by children aged 8 years or older and by those with reduced physical, sensory or

mental abilities, or those lacking experience orknowledge

provided they are correctly supervised, or if the instructions related to the use of the device have been adequately given and if the risks involved have been understood. Children must not play with this device. Children should not clean or maintain the device without supervision.

6. The electrical socket must remain easily accessible if it serves as the means of disconnection.

7. Always unplug the device before cleaning it.

8. Clean the device with a soft dry cloth only. Never use solvents.

9. Attention should be drawn to the environmental aspects of battery disposal.

10. The battery (batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like

#### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not

#### FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## EC Declaration

This product complies with the below listed UK Directives.

Radio Equipment Regulations 2017

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

The Batteries and Accumulators (Placing on the Market) Regulations 2008 (as amended) and the Waste Batteries



Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected. — Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

Electromagnetic Compatibility Regulations 2016. Electrical Equipment (Safety) Regulations 2016.



reminder nofitication.

water deeper than 3.3 ft (1 m).

dried out before charging.

so may cause damage to the speaker.

3.lt may take several minutes for your speaker to begin charging when it's drained. The battery needs to charge to a minimum voltage before the system can boot up.

4.It's recommended to power off the units while the speaker is charging, please don't play music unitl the unit is charged for 30 mintues at least, it will help to extend battery's life and protect untis well.

# Waterproof

CAUTIONS:

BoomPro is rated by IPX7 waterproof. The speaker can be immersed the speaker in water for up to 30 minutes at a depth of up to 3.3ft(1m). It could be also used whiling showering and rainning.


- Please make sure the charging cover is well sealed before you use it. Do NOT submerge this speaker in any pool of

- Never attempt to charge the speaker while it is wet. Doing

- If the speaker is exposed to salt or chlorinated water,

gently rinse with fresh water following the exposure to remove residue. Make sure the connector port is fully

# CHARGING



# **SPECIFICATION**

Model: BOOMPRO Item Ref: Q12 Pro Bluetooth Version: V5.3 SNR:75dB Wireless Working Frequency: 2.402-2.480GHZ Wireless Transmission Distance: up to 33 ft[10M] Charging Time: approx. 3 hours Charging: DC 5 V± 2A Size: 72mm x 188 mm Maximum Operation temperature: 46°C and Accumulators Regulations 2009 (as amended).

Copyright © 2023 MIATONE Inc. All rights reserved. Bluetooth is a registered trademark of Bluetooth SIG, Inc. MIATONE products are registered trademark of MIATONE in the US. Service contact: support@miatone.com MIATONE Inc.Oxnard, CA 93022

www.miatone.com