



2 Outlet BLUETOOTH WATER TIMER

Model: HCT-626



Ideal for watering: lawns, gardens, shrubs, allotments, patios, pots, holiday watering, etc.

DEVICE INTRODUCTION



Working Temperature	3°C - 45°C
Working Pressure	0.05 Mpa-0.8 Mpa
Ingress Protection	IPX5
Power Supply	2 × 1.5 V 'AA' Alkaline Batteries
Applicable Locations	Outdoor

Distance Between Bluetooth Water Timer and Smart Phone
About 15 m (no obstacles between them)

*The Company reserves the right to change the definition and upgrade the device without prior notice.

DOWNLOAD THE APP

1. Search in APP Store / Google Play or scan the QR code of **Smart Life**.



2. Register an account in the APP.

CONNECT THE BLUETOOTH WATER TIMER

1. Take the water timer near your smart phone, turn on the phone Bluetooth and enter the homepage of the APP.

2. Place the batteries into the timer and the light indicators blink quickly to start connection.

* If it does not get paired in 1 min, the light indicators will turn off. Please hold either of the two buttons for 3 sec to reset.


3. Add the timer as promoted by the APP or scan the QR code to add in the APP.



OPERATING INSTRUCTIONS IN APP

QUICK GUIDE:

- After finishing the connection, the timer paired will be displayed on the page.
- Click "2-Outlet Bluetooth Water Timer" and get into the main page of the device.



TIPS:

Remote control and more functions can be achieved if used together with the Company's Bluetooth Gateway.

WEATHER DELAY:

- Click "Weather Delay" and choose the period you want. Schedule plans and Spray plans will not be performed within the set time.
- Once Weather Delay is successfully set, it will work on both Area A and Area B.
- If you want to start "Smart Weather" function, first please add this timer to the Company's Bluetooth gateway.

MANUAL WATERING:


- Click "Manual Watering" to set the runtime and save it.
- Click "⊙" button to start the Manual Watering. When the set runtime is over, the timer will stop watering itself.
- If you want to cancel Manual watering in midway, please Click "⊙" button again.

NOTES:

The connection delay will be about 0.5 to 3 seconds, please do not repeatedly click the button.


SCHEDULE:

- Click "Schedule" and enter the "Add" page.
- Click "Add" to enter the content setting page.
- Set start time, runtime and loop / single time, then click "Save".
- Back to the listing, the on-off button on the right side of the plan will be green, indicating it has been set successfully.
- Up to 5 plans can be added by setting like above steps for each Area.



SPRAY:

- Click "Spray" and enter the content setting page.
- Set start time, end time, spray duration, interval duration and loop / single time, then click "Save" below and on-off button on the upper right corner into green.



TIPS:

Please upgrade the version according to the APP prompts and regularly clean up the cache to ensure that the device can work well.

INSTALLATION

1. Attach the timer to an outdoor hose faucet and the water outlet to the water pipe firmly.

2. An O-ring / adapter / quick connectors / PTFE tape can be used as a protection against water leakage.

3. Turn on the faucet and keep it on.



NOTES:

- When the timer is used, the water inlet must be equipped with a filter to prevent impurities from blocking the valve, which may result in valve switch failure or water leakage. Please clean or replace the filter regularly.
- The timer itself does not generate pressure and needs tap water pressure or water source with pressure to work well.
- The working temperature of the timer is 3°C - 45°C. When it reaches the freezing temperature or the timer is not in use for a long time, please take it off, pick out the batteries, empty the water in the valve tubes, and store it in an indoor dry place.



TROUBLESHOOTING

1. The smart phone Bluetooth is enabled but the APP fails to connect to the Bluetooth Water Timer.

--The distance between the smart phone and the timer maybe exceed the Bluetooth's effective range, please adjust the distance.

2. Long press the reset button for 3 seconds but the indicators do not blink.

--Reinstall / replace the batteries and retry.

3. The hose tap connection / water outlet of the device is leaking.

--The thread is not properly screwed. Please try again.
--The thread does not match. Please use an adapter / quick connector / PTFE tape if needed.

4. Little water flows out when watering.

--There might dirt particles blocked in the valve tube. Please clean the filter in time.
--It is likely the local municipal water pressure is low.

5. No water comes out of the timer within the set time.

--The faucet is off. Please turn it on.
--The batteries are exhausted. Please replace with new ones.
When "⊙" displays on the page, that means the power is about to be exhausted and the timer cannot work properly.
--Weather Delay / Smart Weather is on. Please turn it off.

AFTER-SALES SERVICE

- In case of device performance failures, 1- year-warranty after sale is included (excluding accessories).
- Damages caused by unauthorized maintenance, misuse, collision, negligence, abuse, accident, modification, incorrect use of the device or its parts and force majeure are not covered by the warranty.
- You may contact local distributors or special repair stations with the device invoice and warranty card if your device fails due to quality problems.

WARRANTY CARD

Customer: _____ Tel.: _____

Contact Add: _____

Device Name: _____ Model: _____

Purchase Add: _____ Order Date: _____

DECLARATION ON HAZARDOUS SUBSTANCES IN ELECTRONIC PRODUCTS

PARTS	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Plastic	○	○	○	○	○	○
PCBA	○	○	○	○	○	○
Accessories	○	○	○	○	○	○

This form is compiled in accordance with the requirements of SJ / T11364.

○ Indicates that the concentration of the hazardous substance contained in all the homogeneous materials of this part is below the limit requirement of the GB / T26572 standard.

X Indicates that the concentration of the hazardous substance contained in all the homogeneous materials of this part is above the requirement of the GB / T26572 standard.



FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


Manufacturer:

Ningbo Hanci Electrical Co., LTD.
No.127 -129, Dexing Road, Ninghai County, Ningbo City,
China. 315600

Made in China


BLUETOOTH GATEWAY

Model: HCG-002



By connecting to the Bluetooth gateway, remote control of Bluetooth devices can be achieved via smart phone app.

DEVICE INTRODUCTION



WiFi	2.4 GHz
Bluetooth	4.2 / 5.0
Working Temperature	-10°C - 55°C
Rated Power	< 1.0 W
Power Supply	110 - 240V AC, 50 / 60 Hz
Applicable Locations	Indoor
Distance Between Gateway and Bluetooth Devices	
About 15 m (depending on obstacles between gateway and the devices)	

*The Company reserves the right to change the definition and upgrade the device without prior notice.

DOWNLOAD THE APP

1 Search in APP Store / Google Play or scan the QR code of **Smart Life**.

Smart Life



2 Register an account in the APP.

CONNECT THE BLUETOOTH GATEWAY

- Take the gateway and smart phone near the router (2.4 GHz WiFi only), the closer the better.
- Turn on the phone Bluetooth and enter the APP.
- Plug the gateway into an indoor socket with a plug adaptor.
The light indicator will turn on and few seconds later it will blink slowly, shows it is waiting for network connection.
 - If prompted for connection timeout, please hold the reset button for more than 5 sec till the light indicator blinks slowly.
 - If the light indicator does not blink, please remove and reinstall the gateway, then hold the button again.
- Add the gateway as promoted by the APP or scan the QR code to add in the APP.



OPERATING INSTRUCTIONS IN APP

QUICK GUIDE:

- After finishing the connection, the gateway paired will be displayed on the page.
- Click "Bluetooth Gateway" and get into the main page of the gateway, then add the Bluetooth device as promoted.



Congratulations!

After successful paired, please turn off the smart phone Bluetooth.
Users can remotely control the Bluetooth devices in the APP anytime and anywhere.

TIPS:

- Because of the communication delay, please manually scroll down to refresh every time you enter the APP for data update.
- Due to the upgrades and updates of **Smart Life** APP, the actual operations may be slightly different from the above descriptions. Kindly follow the instructions in current APP.
- Please upgrade the version according to the APP prompts and regularly clean up the cache to ensure that the device can work well.
- The gateway shall be always within the effective range of the router. The WiFi must be 2.4 GHz WiFi network.



TROUBLESHOOTING

- The gateway cannot be connected to the router.**
 - Wrong WiFi frequency. Please change it to 2.4 GHz.
 - Incorrect WiFi password. Please reenter.
 - Weak WiFi signal. Please shorten the distance between the gateway and the router.
 - Smart phone fault. The smart phone is aged with too large memory, which causes jamming during the operation.
- The gateway and the Bluetooth device have been paired but the Bluetooth device cannot be connected via the APP.**
 - Check whether the Bluetooth device has been successfully paired with the gateway. If not, re-pair the device.
 - The Bluetooth device may be beyond the remote control distance of the gateway. Please adjust the position of either the Bluetooth device or the gateway.

Manufacturer:

Ningbo Hanci Electrical Co., LTD.
No.127 -129, Dexing Road, Ninghai County, Ningbo City,
China. 315600
Made in China

AFTER-SALES SERVICE

- In case of device performance failures, 1- year-warranty after sale is included (excluding accessories).
- Damages caused by unauthorized maintenance, misuse, collision, negligence, abuse, accident, modification, incorrect use of the device or its parts and force majeure are not covered by the warranty.
- You may contact local distributors or special repair stations with the device invoice and warranty card if your device fails due to quality problems.

WARRANTY CARD

Customer: _____ Tel.: _____

Contact Add: _____

Device Name: _____ Model: _____

Purchase Add: _____ Order Date: _____

DECLARATION ON HAZARDOUS SUBSTANCES IN ELECTRONIC PRODUCTS

PARTS	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Plastic	○	○	○	○	○	○
PCBA	○	○	○	○	○	○
Accessories	○	○	○	○	○	○

This form is compiled in accordance with the requirements of SJ / T11364.

- Indicates that the concentration of the hazardous substance contained in all the homogeneous materials of this part is below the limit requirement of the GB / T26572 standard.
- X Indicates that the concentration of the hazardous substance contained in all the homogeneous materials of this part is above the requirement of the GB / T26572 standard.



QUICK GUIDE



Keep your Bluetooth water timer, Bluetooth gateway, smartphone and router close to each other while adding devices.

DOWNLOAD THE APP

Search for "Smart Life" in APP Store / Google Play, download the APP and click "Register" to sign up an account.



Smart Life APP

Also you can scan the QR code to download the APP.

Due to the upgrades and updates of the APP, the actual operations may be slightly different from the following descriptions. Kindly follow the instructions in the current APP.

01

CONNECT THE BLUETOOTH WATER TIMER



1. Open the APP.

02



Hold either of the two buttons until the light blinks.



2. Click "+" - "Add Device".

03



3. Turn on the phone "Bluetooth".



4. Add the timer in the APP.
Pull down the page to refresh if no product appears.

04




5. Click "Done".



6. Start your operation.

05



For remote control, please add the Bluetooth Gateway.

CONNECT THE BLUETOOTH GATEWAY




Hold the button until the light blinks.



1. Go back to home, click "+" - "Add Device".

06



2. Add the gateway in the APP.
Pull down the page to refresh if no product appears.

07



3. Enter Wi-Fi information.
A stable 2.4Ghz WiFi network is needed.



4. Click "Done".

08




5. Click "Bluetooth Gateway".



6. Click "+ Add device".

09




7. Click "Add existing".



8. Select the device to connect.

10



9. Click "2-Outlet Bluetooth Water Timer".



10. Start your operation.

11



Turn off the phone Bluetooth.
remote control

Congratulations!
Enjoy your smart watering in the APP anytime anywhere.