

Power On

Step 1: Thread the longer band through the first loop of the shorter band.


Step 2: Adjust to a comfortable tightness, then press the holes on the longer band onto the metal pin buckle of the shorter band





approximately 10 minutes and wait for it to power on automatically

Charging cable



Step 1: Download the Fitbeing app

Go to the app store on your phone, search for *Fitbeing*, an install it. Open the Fitbeing app and select "Set Up a Device" on the

· For Android phones, go to the Google Play. · For iPhone, go to the App Store.

Step 2: Pair with the App

S1G" via Bluetooth. Then you can start using the watch.

home page. Follow the instructions to pair your "Kriki Watch

Search via Bluetooth

2. To ensure successful pairing, please grant Fitbeing App permissions to access Bluetooth, Location, and Camera on



Common Functions

Notification Center

Swipe down on the watch face screen.

To access the Control Center, swipe up on the watch

Sleep, Recently, Weather, or Workout tiles, swipe left or

ight on the watch face screen

face screen. Enable features like Silent Mode, Sleep

Mode, Always-on Display, and adjust brightness and



Digital Crown Operation

Support full-screen touch (swipe, tap, touch and hold) 1. Press the digital crown to wake up the screen.

Touchscreen Operation

You can also scan the QR code on the left to

quickly go to the *Fitbeing* app in the app

store, and install it.

4 Get Started

Set up the Watch



Press the Digital Crown until the startup screen appears.



Swipe right

3. Exit the app


1. Toggle between screens or navigate through menus.

2. Press the digital crown to enter the app center

restarting the watch.

2. Adjust the volume of prompt tones and phone calls.





Change the Watch Face

Record Workouts

app and select a specific workout.


To start your workout recording, access the Workout

Health Metrics Measurement

When wearing the watch, it automatically measures Photo every time you raise your wrist or tap the screen. health data such as heart rate, sleep, stress, and activity. ou can also view and track this data in the application. Add Photos You can choose up to 3

Install New Watch Faces

In the Fitbeing app, navigate to the To charge the watch, connect the charging cable to a USB power source. Attach the other end to the charging contact on the back of the watch. The watch will display a charging icon while it is being charged. Face Gallery page to pick up your




To change the watch face, press and hold the screen for 1 second to access the watch face Face Gallery



1. Lift the spring bar from the groove.

2. Push and hold the spring bar. 3. Pull it out gently to remove the band.






· Prior to charging, ensure to clean the charging

lingering sweat or moisture.

1. Insert the metal pin at position "A" in the hole.




Install band

· Ensure to use a standard USB power source with an output of 5V---1A or abovi

2. Push and hold the spring bar.

3. Press the band into the body and release the spring bar. 4. Pull the watch band to confirm the firm installation.



Wear and Care

take off the watch and rest your wrist.

Key Specifications

Product Name

Wireless Connection

Satellite positioning

Working Temperature

Compatible Operating Systems

Body Dimension

Water resistance garde

It is advised to remove the watch for approximately one hour daily. If you experience discomfort or irritation like redness, tingling, or a burning sensation,

To maintain hygiene, regularly clean your watch and wrist, particularly after workouts and sweating. Avoid using hand soap, shower gel, dishwashing liquid, or cleaning wipes as they can cause skin irritation. Instead, use mild soap and fresh water to clean the band.

Kriki Watch S1G

46.5mm \times 39.6mm \times 11.4mm

iOS 13.0 and above, Android 9.0 and above

Design for Comfortable Wearing

The inner sweat grooves of the band are specifically designed

to minimize skin irritation resulting from sweat, moisture, and · Avoid forcibly opening the watch case, as it may cause short circuits and prolonged wear. overheating.

> · Keep the watch away from environments exceeding 60°C to prevent battery leakage or explosion.

· While the product complies with IP68 waterproof standards, it is not recommended for activities such as bathing, diving, or water skiing that involve protection against harmful interference in a residential installation. This equipment generat

high temperatures, steam, or rapid water flow. uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no Note that the waterproof performance may be compromised if the product

guarantee that interference will not occur in a particular installation. If this equipment does structure is damaged.

more of the following measures: detailed information, please refer to the product's upgrade instructions.

Connect the equipment into an outlet on a circuit different from that to which the receiver is

Consult the dealer or an experienced radio/TV technician for help.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, cience and Economic Development Canada's licence-exempt RSS(s). Operation is subject to

Any changes or modifications not expressly approved by the party responsible for compliance

radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

Precautions

Help and Guide

for assistance.

Product Manual

"Profile \rightarrow User Guide".

Frequently Asked Questions

If you encounter any problems while using the product, you can

access the "Profile ightarrow Help & Support" section in the Fitbeing app

Scan the QR code on the right to access or visit help.fitbeing.com for

You can find the complete product manual in Fitbeing app at

Scan the QR code on the right to access it, or visit help.fitbeing.com to

could void the user's authority to operate the equipment. · Do not replace the built-in battery yourself as it may pose a safety risk This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

1. this device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause

device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

cause harmful interference to radio or television reception, which can be determined by turning Be aware that firmware upgrades can lead to interface and usage changes. F the equipment off and on, the user is encouraged to try to correct the interference by one or

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

FCC Requirement

he following two conditions: 1. This device may not cause interference.

émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux

1. L'appareil ne doit pas produire de brouillage;

2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



2. This device must accept any interference, including interference that may cause undesired

