

Positive Grid®

Welcome to Spark GO.
Check out this guide to
set up your personal jam space.

Spark GO


QUICK START GUIDE



■ What's In The Box?



Spark GO Amplifier



Carrying Strap x2




Strap Button



Alternate Grille



**Quick Start Guide and
Safety Instructions**



**USB-C® to USB-A
Charging Cable**

■ Get Started

Download and install the Spark app to unlock all of your Spark's smart features, gear, and more!




App Store
iOS 11 or later

Google Play
Android 8 or later




- Download the Spark app using the QR code above or search for “Spark amp” in the App Store or Google Play.
- Turn on Spark GO by holding the Power button until the LED illuminates, then open the Spark app on your mobile device.
- Tap Connect and the Spark app will search for your Spark GO. Select yours from the list and you're ready to play.


■ Using Spark GO as a Guitar Amp



- Plug your guitar into the Guitar Input jack on the top control panel.



- Select one of the four presets available and adjust the volume by using the Guitar Volume knob on the top control panel.




- To access more tones and create your own, download the Spark app using the QR code on page 1 or search for "Spark amp" in the App Store or Google Play.

■ Using Spark GO as a Wireless Bluetooth® Speaker



- When connecting to Spark GO for the first time, turn Bluetooth® on in your mobile device settings, and select “Spark GO Audio” from the list of scanned devices.
- Spark GO will automatically pair with the last device it was connected to. If the last device is not available, Spark GO will automatically connect to a device that has been previously paired.
- To pair a new device, press the Power/Pair button on the side panel, turn Bluetooth® on in your mobile device settings, and select “Spark GO Audio” from the list of scanned devices.

■ Top Control Panel



A**Preset Selector**

Press the preset button to select one of four presets on Spark GO. These presets can also be customized in the Spark app. The red LED indicates the preset currently in use. Hold the Preset button to enter Tuner Mode.

B**Music Volume**

Adjusts the sound volume of Bluetooth® devices.

C**Headphone/Line Out (3.5mm)**

Plug in a pair of headphones with a 3.5mm jack. Note that sound will not come out of Spark GO's main speaker when headphones are plugged in.


D**Guitar Input**

Plug in your guitar with a standard 1/4" (6.3mm) guitar cable.

E**Guitar Volume**

Adjusts the overall volume of your guitar.

■ Side Panel





Bluetooth® Indicator

Indicates the status of your Bluetooth® audio connection.

- Solid Blue: Connected.
- Flashing Blue: Pairing.



Power/Pair Button

- Hold to turn Spark GO on or off.
- Press to enter Bluetooth® pairing mode when connecting to a new device.



Power Indicator

Indicates power and battery status.

- Solid Green: Powered on or fully charged.
- Solid Red: Low battery.
- Flashing Red/Green: Charging.




USB Port

Connect the included USB-C® to USB-A cable to charge Spark GO.

■ Grille & Strap Swapping


Grille

- Remove the current grille by detaching it gently from the bottom edge of Spark GO with your fingertips or a guitar pick.
- Insert a new grille by lining up the magnetic pegs with the holes in the cabinet. The new grille will then snap into place.



Strap

- Remove and swap out the strap by unscrewing the button that attaches it on the side of Spark GO.



APP DOWNLOAD



Download the Spark app using the QR code above or search for “Spark amp” in the App Store or Google Play.

USER MANUAL & SUPPORT



Learn about all the smart features, gear customization, and more available in the Spark app.

Declarations of Conformity

• BATTERIES

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the light.

- 1) Replacement of a battery with an incorrect type that can defeat a safeguard;
- 2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- 3) Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- 4) A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

• CQC

注意事项：

1. 勿在本机顶部或电源线上放置重物。
 2. 仔细阅读操作说明避免误操作。
 3. 设备不应遭受水滴或水溅，设备上不应放置诸如花瓶一类的装满液体的物品，否则水等液体的不小心洒泼可能会损坏机器。
 4. 本产品不与电网电源直接连接。
 5. 电池（电池包或组合电池）不得暴露在诸如日照、火烤或类似过热环境中。
 6. 消费者若使用电源适配器供电，则应购买配套使用获得CCC认证并满足标准要求电源适配器。
- 注意：如果电池更换不当会有爆炸危险，只能用同样类型或等效类型的电池来更换。

• TRIMAN



FR
Cet appareil,
ses accessoires,
cordons et batteries
se recyclent

À DÉPOSER
EN MAGASIN

À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

• WEEE



進口商/进口商 & 製造商：佳格數位科技有限公司 / 佳格數位科技有限公司

地址：台北市中山區長春路176號11樓/台北市中山區長春路176號11樓



Positive Grid®

Visit our online Help Center for user manuals, FAQs,
or to contact our support team: help.positivegrid.com

● RoHS

設備名稱Equipment name：吉他音箱 型號（型式）Type designation (Type)：Spark GO						
單元Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					R3D776 RoHS
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ^{VI})	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
揚聲器	○	○	○	○	○	○
電路板	-	○	○	○	○	○
結構件	-	○	○	○	○	○
線材	○	○	○	○	○	○
配件	○	○	○	○	○	○

備考1.“超出0.1 wt %”及“超出0.01 wt %”係指限用物質之百分比含量超出百分比含量基準值。
備考2.“○”係指該項限用物質之百分比含量未超出百分比含量基準值。
備考3.“-”係指該項限用物質為排除項目。

Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.
Note 2: "○" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.
Note 3: The "-" indicates that the restricted substance corresponds to the exemption.

有毒有害物質或元素的說明 Indication of Toxic and Hazardous Substances/Elements						
部件名稱 Part name	產品中有毒有害物質或元素的名称及含量 Toxic and Hazardous Substances/Elements					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr(VI))	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
揚聲器 (Speaker)	○	○	○	○	○	○
電路板 (PCBA)	X	○	○	○	○	○
結構件 (Structural parts)	X	○	○	○	○	○
線材 (Cable)	○	○	○	○	○	○
附件 (accessory)	○	○	○	○	○	○
電池 (battery)	○	○	○	○	○	○

本表格依據 SJ/T 11364 的規定編制

○:表示該有毒有害物質在該部件所有均質材料中的含量均在GB/T 26572規定的限量要求以下
X:表示該有毒有害物質至少在該部件的某一均質材料中的含量超出GB/T 26572規定的限量要求

 在中華人民共和國境內銷售的電子電氣產品上將印有“環保使用期”(EFuP)符號。圓圈中的數字代表產品的正常環保使用年限。

●FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: FCC/IC Radiation Exposure Statement

This equipment complies with FCC and IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Pour se conformer aux exigences de conformité CNR 102 RF exposition, une distance de séparation d'au moins 20 cm doit être maintenue entre l'antenne de cet appareil et toutes les personnes. Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

● IC

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes :
1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même s'il brouillage est susceptible d'en compromettre le fonctionnement.

This class [B] digital apparatus complies with Canadian ICES-003.

CAN ICES-003 (B) / NMB-003 (B)

Ce produit de classe [B] est conforme aux spécifications de la réglementation ICES-003 du Canada. CAN ICES-003 (B) / NMB-003 (B)

● NCC

警語：

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

● BSMI

1. 在使用過程中，應遠離熱源、高壓，避免兒童玩弄電池，切勿摔打電池。
2. 廢棄電池請安全妥當處理，不要投入火中或水中。
3. 禁止拆裝電池，電池內部具有保護機構和保護電路可以避免發生危險。不合適的拆裝會損壞保護功能，將會造成讓電池發熱、冒煙、變形或燃燒。
4. 不可將電池用於其他設備，不恰當使用會損壞電池的性能、降低壽命，甚至會使電池發熱、冒煙、變形或燃燒。
5. 不要直接觸及漏液電池，滲漏的電解液會造成皮膚不適，萬一電解液進入眼睛，儘快用清水沖洗，不可揉眼，並迅速送醫院處理。
6. 不可與其他電池混用電池，不可與其他類型的一次或二次電池混用，否則因為不正常的充、放電造成電池發熱、冒煙、變形或燃燒。