GravaStar

MERCURY K1 Lite 75% Wireless Mechanical Gaming Keyboard
Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State of the state Image: State Image: State
User Manual



- Number of keys: 80
- Keyboard switch type: Mechanical switch
- Bluetooth version: V5.0
- Bluetooth name: K1 LITE
- Wireless distance: >10 meters
- Battery capacity: 4000mAh
- Battery life:
- Approximately 20H (default lighting effects)
- approximately 666H (with all lights off)
- Input: DC 5V~1200mA
- Charging time: About 5H
- Interface type: Type-C
- Product dimensions: 343*156*46 mm
- Product weight: 0.85KG
- System Support: Windows XP and above / Mac



Keyboard x 1 2.4G Receive x 1 USB-A to USB-C Cable x 1 User Manual x 1 Switch Puller x 1

01

in + Left WIN Indroid/MA When switch	I = Lock/Unloc C/IOS system led to Mac sys	ck the left WIN s). item, the posi	ode Swi I key (when W tions of left W apped(WIN no	IN is locked, the IN/left ALT are	he WIN indicates			ned to	
WIN LEFT WIN LEFT ALT RIGHT ALT									
	Мас	L	EFT Option	n I	LEFT Command		RIGHT Command		
Hotkey Instructions									
(Make sure the left switch is set to the corresponding mode FN+`~/1/2/3 to enable pairing)									
Fn+	ESC	•~	1!	2@	3@	M	TAB	1	
Combination	Restore Factory	2.4G	Bluetooth	Bluetooth	Bluetooth	Switch Key Backlight	Switch Key Backlight	Increase Kev	

et t	o the corre	sponding n	node FN+`~	-/1/2/3 to e	enable pair	ing)
	1!	2@	3@	М	ТАВ	1
	Bluetooth Device 1#	Bluetooth Device 2#	Bluetooth Device 3#	Switch Key Backlight Effects	Switch Key Backlight Color	Increase Key Backlight Brightness
	\rightarrow	WIN-L	DEL	PGUP	PGDN	U
ley	Increase Key Backlight Speed	WIN System Lock WIN and APP	Insert	HOME	END	Print Screen
	P					

Windows operating system

(single key press function of the F key and FN key combination function with the F key)

				-		-					-
Кеу	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11
Single Press	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11
Fn Combination	Home	Email	Switch Window	Open File Explorer		Increase Brightness	Previous Track	Play/ Pause	Next Track	Mute	Volume Down

Æ c System



Кеу	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11
Single Press	Decrease Screen brightness	Increase Screen brightness	Switch window	Return to desktop	Decrease Brightness	Increase Brightness	Previous Track	Play/ Pause	Next Track	Mute	Volume Down
Fn Combination	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11

Fn+

Fn+

Combination Functions

1

Scroll Lock

Combination Functions Decrease Key Backlight Brightness

←

0

Pause

Battery Indicator

Decrease H Backlight Speed

05

Functions)		Connection Methods
Connection Mode Toggle Switch		ng RGB,	 2.4G Connection: Toggle the switch on the left to 2.4G mode, "~" key's cyan light seconds until the cyan light flashes quickly to enter pairing mode. At this point, in The "~" key's cyan light will stay on for 2 seconds, indicating a successful 2.4G co 2.4G, search first before inserting the receiver). The factory default is pre-paired, inserting the USB receiver into the computer's USB port. Bluetooth Connection: Toggle the left switch to Bluetooth mode BT3.0/BLE5.0 (D Depending on the Bluetooth version of the terminal device, it will broadcast rand connected: Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected Image: The blue indicator flashes quickly when broadcasti for 3 seconds when connected
02			03

		Lighting Effects
y)		Key Backlight Effects
F11	F12	 Fn + " " key combination = Switch between 13 types of RGB backlight effects: Wave (default effect after reset), Shadow Follow, Sine Wave, Spinning Windmill, Colorful Waterfall, Prosperous Bloom, Gaming Mode, Off Constant Light Mode, Dream Rainbow, Instant Trigger, Key Ripple, Starry Sky.
		Fn] + []] = Increase Brightness Fn] + []] = Decrease Speed []Fn] + []TAB] = Switch Backlight Color
F11	F12	Fn] + [] = Decrease Brightness Fn] + [] = Increase Speed
Volume Down	Volume Up	Battery Display
		buttery bispidy
		 Press and hold Fn + B to check. 1~0 indicates batterylevel: all green when fully charged, green lights gradually decrease as battery is consumed, if battery <30% 1-3 ights turn red, if battery ≥30% 1-0 lights remain green. Release to restore the light effect. When battery is low, the FN key flashes red. During charging, the FN key lights up red continuously, and turns off when fully charged. Battery status can be displayed on the computer when connected via Bluetooth
F11	F12	Factory Reset
FII		• Press and hold Fn + Esc for three seconds to restore defaults. Previously connected Bluetooth devices will remain saved.
Volume Down	Volume Up	Software Download
F11	F12	• To download the driver, please visit gravastar.com to get the download link.
		You can define your preferred key functions, combination functions, backlight effects, etc., through the driver software.
		06

GravaStar



Gra	
	Ø
€ [®] xxx-xxxxxx ∛	∕ ð

Manufacturer: ZhuoYe ChuangYi Co. Ltd Address: Room 602-1 Building 6 Shenzhen Bay Eco-Tech Park, Nanshan District, Shenzhen City, Guangdong Province, China

will flash slowly. Then, press FN+"~" for 3 nsert the receiver to complete the pairing. nnection. (Note: When connecting via l, so you can automatically connect by

- Device name: K1 LITE_3.0/K1 LITE_5.0)
- domly, and up to 3 devices can be
- ing, reconnects slowly, and stays on
- ting, reconnects slowly, and stays on
- ing, reconnects slowly, and stays on
- " key stays on for 3 seconds.





Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.