



GE5 PRO中英文中性说明书 尺寸:83\*86mm\*6页 材质:105g双铜单黑双面印刷

<div data-bbox="337 372 1262 751"><p>The image shows a pair of white wireless earbuds with black tips, resting inside their white charging case. The case is open, revealing the earbuds and a black LCD touch screen on the inside of the lid. The screen displays battery levels for both earbuds and the case, along with a signal strength indicator. The ANC logo is visible on the earbuds.</p></div> <div data-bbox="337 751 1262 844"><h3>无线耳机</h3><p>使用说明书</p></div>	<div data-bbox="1262 372 2247 751"><h3>产品参数</h3><ul style="list-style-type: none"><li>◎ 无线版本: V5.4</li><li>◎ 工作范围: 无障碍10米</li><li>◎ 无线频率: 2.402-2.480GHz</li><li>◎ 充电盒容量: 3.7V, 300mAh</li><li>◎ 充电输入: DC 5V-500mA</li><li>◎ 充电时间: 约2小时</li><li>◎ 耳机内置电池: 3.7V, 30mAh*2</li><li>◎ 播放音乐: 约4.5小时 (80%音量)</li><li>◎ 通话时间: 约4小时 (80%音量)</li><li>◎ 充电盒给耳机充电次数: 约4次</li><li>◎ 充放电循环: ≥300次</li><li>◎ 充电端口: Type-C</li></ul></div> <div data-bbox="1262 751 2247 844"><p>注: 本产品规格参数均为实验室测试数据, 不同环境使用会有所不同; 产品不断升级改进, 具体功能和产品图片可能与实物略有不同, 请以实物为准。</p></div>	<div data-bbox="2247 372 2723 751"><h3>操作方式: 耳机</h3><ul style="list-style-type: none"><li>• 开机: 打开充电盒盖, 耳机自动开机, 等待蓝牙连接</li><li>• 关机: 耳机放入充电盒, 关闭盖子后自动充电, 约1.5小时充满</li><li>• 配对模式: 耳机开机后自动进入配对模式</li><li>• 暂停/播放: 单击左或右耳机</li><li>• 接听来电: 单击左或右耳机</li><li>• 挂断电话: 双击左或右耳机</li><li>• 来电拒接: 长按左或右耳机2秒</li><li>• 下一曲: 三击右耳机</li><li>• 上一曲: 三击左耳机</li><li>• 音量-: 向下滑动左/右耳机减小音量</li><li>• 音量+: 向上滑动左/右耳机增加音量</li><li>• 语音助手: 长按左耳机2秒</li><li>• ANC降噪功能: 长按右耳机2秒, ANC ON-ANC OFF-通透模式循环操作</li><li>• 音乐模式 (默认): 在游戏模式下, 4连击左或右耳机切换到音乐模式</li><li>• 清除配对设备列表: 同时6连击左和右耳机</li><li>• 入耳检测: 安卓默认关闭, IOS默认开启, 5连击可开启或关闭入耳检测</li></ul></div> <div data-bbox="2247 751 2723 844"><h3>无线连接时注意事项</h3><p>1、请将无线耳机和手机 (或其他连接设备) 的距离控制在1米的范围内, 越近越好;</p></div>	<div data-bbox="2723 372 3171 751"><h3>充电</h3><ul style="list-style-type: none"><li>• 耳机电量低提醒: 当电池电压低于3.3V时, 每隔1分钟提醒一次</li><li>• 耳机充电: 耳机放入充电盒, 关闭盖子后自动充电, 约1.5小时充满</li><li>• 充电盒电量低提醒: 电量低于10%时, 充电仓图标显示红色 (充电仓电压低于3.4V时, 充电仓自动关机, 彩屏不显示)</li><li>• 充电盒充电: 彩屏显示充电图标, 30秒后熄灭, 约1.5小时充满电</li></ul></div> <div data-bbox="2723 751 3171 844"><h3>注意事项</h3><ol style="list-style-type: none"><li>1、切勿使用具有腐蚀性的清洁剂清洁本产品;</li><li>2、切勿让本产品加热或靠近火源, 如煮食炉;</li><li>3、切勿让本产品长时间受阳光直接照射, 避免高温;</li><li>4、切勿将本产品弃置于火中, 避免发生爆炸;</li><li>5、切勿尝试拆开本产品作出任何修改, 因为它并不包含任何维修组件;</li><li>6、切勿在雨中使用本产品;</li><li>7、如果长期期内不打算使用本产品, 请您将它存储在干燥的环境中, 并每月至少为耳机充电一次以延长寿命, 避免极端的温度和灰尘。</li></ol></div>
---	---	---	---

<div data-bbox="323 947 1265 1169"></div> <div data-bbox="323 1169 1265 1441"><h3 data-bbox="323 1169 1265 1183">Wireless Earphones</h3><p data-bbox="323 1183 1265 1199">user manual</p></div>	<div data-bbox="1265 947 2243 1169"><h3 data-bbox="1265 947 2243 963">Product parameters</h3><ul data-bbox="1265 963 2243 1169" style="list-style-type: none"><li>●Wireless version: V5.4</li><li>●Working range: barrier-free 10 meters</li><li>●Wireless frequency: 2.402-2.480GHz</li><li>●Charging box capacity: 3.7V, 300mAh</li><li>●Charging input: DC 5V-500mA</li><li>●Charging time: about 2 hours</li><li>●Earphone built-in battery: 3.7V, 30mAh*2</li><li>●Play music: about 4.5 hours (80% volume)</li><li>●Talk time: about 4 hours (80% volume)</li><li>●Number of times the charging case charges the earphones:About 4 times</li><li>●Charge and discharge cycle: ≥300 times</li><li>● Charging port: Type-C</li></ul></div> <div data-bbox="1265 1169 2243 1441"><p data-bbox="1265 1169 2243 1183">Note: The specifications and parameters of this product are all laboratory test data, which will be different in different environments; the product is constantly being upgraded and improved, and the specific functions and product pictures may be slightly different from the actual product, please refer to the actual product.</p></div>	<div data-bbox="2243 947 2727 1169"><h3 data-bbox="2243 947 2727 963">Operation Method - Earphones</h3><ul data-bbox="2243 963 2727 1169" style="list-style-type: none"><li>• Power on: Open the charging case cover, the headphones will automatically turn on, wait for Wireless connection</li><li>• Power off: Put the earphones into the charging case, And close the charging case cover</li><li>• Pairing mode: The earphones automatically enter pairing mode when turned on</li><li>• Pause/Play: Click on the left or right earphones</li><li>• Answer incoming calls: Click on the left or right earphones</li><li>• Hang up the phone: Double click on the left or right earphones</li><li>• Call rejection: Long press the left or right earphones for 2 seconds</li><li>• Next song: Three clicks on the right earphone</li><li>• Previous song: Three clicks on the left earphone</li><li>• Volume-: Swipe down the left/right earphones to decrease volume</li><li>• Volume+: Slide up the left/right earphones to increase volume</li><li>• Voice assistant: Long press the left earphone for 2 seconds</li><li>• ANC noise reduction function: Long press the right earphone for 2 seconds, and the ANC ON-ANC OFF - transparent mode will cycle through operation</li><li>• Music mode (default): In game mode, switch to music mode by 4 consecutive clicks on the left or right earphones</li><li>• Clear paired device list: Simultaneously clicking on the left and right earphones 6 times in a row</li><li>• In-ear detection: Android defaults to off, IOS defaults to on, 5 consecutive clicks can turn on or off in ear detection</li></ul></div> <div data-bbox="2243 1169 2727 1441"><h3 data-bbox="2243 1169 2727 1183">charging</h3><ul data-bbox="2243 1183 2727 1441" style="list-style-type: none"><li>• Reminder of low headphone battery: When the battery voltage is below 3.3V, remind every 1 minute</li><li>• Earphone charging: Put the earphones into the charging case, close the lid, and automatically charge them. It takes about 1.5 hours to fully charge them</li><li>• Low battery reminder for charging case: When the battery level is below 10%, the charging case icon displays red (When the voltage of the charging case is below 3.4V, the charging case will automatically shut down and the color screen will not display)</li><li>• Charging case charging: The color screen displays the charging icon, which goes off after 30 seconds and takes about 3 hours to fully charge</li></ul></div>	<div data-bbox="2727 947 3186 1169"><h3 data-bbox="2727 947 3186 963">Considerations when connecting wirelessly</h3><ol data-bbox="2727 963 3186 1169" style="list-style-type: none"><li>1. Please control the distance between the wireless headset and the mobile phone (or other connected equipment) within 1 meter, the closer the better;</li><li>2. Open the charging case cover to connect;</li><li>3. When connecting, make sure that the left and right earphones are interconnected and in the on state;</li><li>4. The charging box needs to have enough power. If the headphones cannot be turned on when the cover is opened, put the headphones in the charging box, close the cover of the charging box and plug in the charger to charge for at least one hour;</li></ol></div> <div data-bbox="2727 1169 3186 1441"><h3 data-bbox="2727 1169 3186 1183">Precautions</h3><ol data-bbox="2727 1183 3186 1441" style="list-style-type: none"><li>1. Never use corrosive cleaning agents to clean this product;</li><li>2. Do not allow this product to heat or come close to fire sources, such as cooking stoves;</li><li>3. Do not expose this product to direct sunlight for a long time to avoid high temperature;</li><li>4. Do not dispose of this product in fire to avoid explosion;</li><li>5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components;</li><li>6. Do not use this product in the rain;</li><li>7. If you do not plan to use this product for a long period of time, please store it in a dry environment.And charge the headset at least once a month to extend the life and avoid extreme temperatures and dust.</li></ol><p data-bbox="2727 1397 3186 1441">※ First use requires charging or long pressing the button for 6 seconds to activate the charging case</p></div>
--	---	---	---

**FCC Warning Statement:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **FCC Radiation Exposure Statement**

The device has been evaluated to meet general RF exposure requirement.  
The device can be used in portable exposure condition without restriction.