

<div data-bbox="301 340 605 376" data-label="Section-Header"><h2>Smart Water Timer</h2></div> <div data-bbox="288 446 625 867" data-label="Image"></div> <div data-bbox="433 959 446 978" data-label="Text"><p>1</p></div>	<p>Congratulations on the purchase of your ECFPOWER Smart Hose Faucet Timer! Faucet watering has never been faster, easier or more convenient with the ability to control it from your phone.</p> <p>You can schedule, manually operate without climbing through your shrubs to access the timer. You can connect to your timer with the push of a button via the home screen in the app. It also allows you to water down to minutes, which is great for gardening, hydroponics, filling pet dishes or even bird baths.</p> <p>Whatever your connected outdoor watering needs, ECFPOWER provides best-in-class smart products to help you more effectively manage and control your watering. Thanks for your purchase, and welcome to ECFPOWER.</p>	<div data-bbox="1213 293 1499 313" data-label="Section-Header"><h3>Meet the Hose Faucet Timer</h3></div> <div data-bbox="1213 327 1646 709" data-label="Image"></div> <div data-bbox="1213 723 1664 956" data-label="Text"><p>Range: 50ft without interference Pressure operating range: 7.2-116 psi Temperature operating range: 40.1°F-113°F (4.5°C-45 °C) For outdoor use with cold water only, Not suitable for drinking water Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries. Used up or dead batteries must be removed from the timer and disposed of properly.</p></div> <div data-bbox="1403 959 1417 978" data-label="Text"><p>3</p></div>	<div data-bbox="1714 318 1959 338" data-label="Section-Header"><h3>Initial Water Timer Setup</h3></div> <div data-bbox="1714 360 1955 379" data-label="Section-Header"><h4>1) Insert Two AA Batteries</h4></div> <div data-bbox="1714 404 2140 454" data-label="Text"><p>Batteries are not included and you will need two alkaline AA batteries to power your timer.</p></div> <div data-bbox="1714 490 2156 942" data-label="Image"></div> <div data-bbox="1916 959 1930 978" data-label="Text"><p>4</p></div>
<div data-bbox="244 1014 655 1208" data-label="Image"></div> <div data-bbox="244 1233 601 1250" data-label="Caption"><p>e. Assemble as shown f. OK</p></div> <div data-bbox="244 1294 424 1313" data-label="Section-Header"><h4>2) Install the Timer</h4></div> <div data-bbox="244 1333 682 1422" data-label="Text"><p>Connect the timer to an outdoor hose faucet. Your timer is now ready to be used with any product that can be attached to a standard hose faucet.</p></div> <div data-bbox="244 1438 669 1530" data-label="Text"><p>! Do not place the timer in an underground valve box or anywhere your Bluetooth signal will be obstructed.</p></div> <div data-bbox="244 1563 455 1582" data-label="Section-Header"><h4>3) Turn on Your Water</h4></div> <div data-bbox="244 1602 637 1654" data-label="Text"><p>The water must remain on for the timer to work properly.</p></div> <div data-bbox="419 1679 433 1699" data-label="Text"><p>5</p></div>	<div data-bbox="730 1020 1009 1039" data-label="Section-Header"><h3>Meet the App Home Screen</h3></div> <div data-bbox="712 1155 1143 1560" data-label="Image"></div> <div data-bbox="932 1679 945 1699" data-label="Text"><p>6</p></div>	<div data-bbox="1208 1017 1483 1036" data-label="Section-Header"><h3>Initial Smart Life App Setup</h3></div> <div data-bbox="1208 1056 1505 1075" data-label="Section-Header"><h4>1) Download the Smart Life App</h4></div> <div data-bbox="1208 1094 1680 1178" data-label="Text"><p>If you don't already have the Smart Life App on your smart device, search for "Smart Life" and download the free Android or IOS app.</p></div> <div data-bbox="1283 1200 1519 1311" data-label="Image"></div> <div data-bbox="1208 1322 1462 1341" data-label="Section-Header"><h4>2) Open the Smart Life App</h4></div> <div data-bbox="1208 1358 1664 1410" data-label="Text"><p>Create an account or login with an existing account to begin timer setup.</p></div> <div data-bbox="1208 1424 1456 1444" data-label="Section-Header"><h4>3) Enter configuration Mode</h4></div> <div data-bbox="1208 1455 1644 1507" data-label="Text"><p>Long press the On/OFF button for 6s until the green light flashes quickly, and then enter the pairing mode.</p></div> <div data-bbox="1274 1521 1412 1657" data-label="Image"></div> <div data-bbox="1417 1604 1601 1624" data-label="Caption"><p>Press 6S until light flash</p></div> <div data-bbox="1403 1679 1417 1699" data-label="Text"><p>7</p></div>	<div data-bbox="1694 1022 1841 1042" data-label="Section-Header"><h4>4) Add a Device</h4></div> <div data-bbox="1694 1056 2156 1167" data-label="Text"><p>Tap "Add device" or "+" to add the smart device in app. Select "Industry&Agriculture" > "Water valve controller(BLE)". Waiting for connecting to be 100%. Edit the name of your water timer completed.</p></div> <div data-bbox="1700 1222 2122 1574" data-label="Image"></div> <div data-bbox="1934 1679 1948 1699" data-label="Text"><p>8</p></div>
<div data-bbox="238 1771 562 1790" data-label="Section-Header"><h3>Additional Water Timer Features</h3></div> <div data-bbox="238 1815 399 1835" data-label="Section-Header"><h4>Manual Watering</h4></div> <div data-bbox="233 1854 700 2056" data-label="Text"><p>Your timer has the ability to allow you to manually water without disturbing the programmed schedule. Manual is used to test equipment, run an extra watering cycle in an area, or to use the hose faucet without removing the timer. Press the ON/OFF button to activate manual watering. Using the app you can set how long you want the preset manual cycle to run for.</p></div> <div data-bbox="238 2095 376 2115" data-label="Section-Header"><h4>Stop Watering</h4></div> <div data-bbox="233 2128 687 2212" data-label="Text"><p>You can stop the flow of water at any time whether it is during manual watering, or during a programmed time. Press the ON/OFF button once to stop watering.</p></div> <div data-bbox="238 2239 342 2259" data-label="Section-Header"><h4>Rain Delay</h4></div> <div data-bbox="233 2270 689 2411" data-label="Text"><p>Prevent watering when rain is in the forecast , you can temporarily suspend your watering program for up to 24H, 48H, 72H using the rain delay feature. After the selected delay has ended,your watering program will automatically resume.</p></div> <div data-bbox="419 2414 433 2433" data-label="Text"><p>9</p></div>	<div data-bbox="730 1771 839 1790" data-label="Section-Header"><h3>Warm Tips</h3></div> <div data-bbox="723 1804 1179 2079" data-label="List-Group"><ol style="list-style-type: none">1. When expecting freezing temperatures, timer should be removed from the faucet and stored indoors to avoid potential freeze damage.2. Please remember to clean the filter regularly and replace it if worn.3. The installation direction of the product is top in and bottom out, otherwise the valve cannot be closed.4. When installed, the rotary hose faucet connection, do not rotate the product, otherwise it will cause the valve head off</div> <div data-bbox="954 2414 982 2433" data-label="Text"><p>10</p></div>	<div data-bbox="1217 1754 1383 1774" data-label="Section-Header"><h3>Troubleshooting</h3></div> <div data-bbox="1217 1785 1619 1832" data-label="Text"><p>Q: Why the bluetooth water timer didn't turn on/off at preset time?</p></div> <div data-bbox="1217 1840 1238 1860" data-label="Text"><p>A :</p></div> <div data-bbox="1217 1868 1533 2029" data-label="List-Group"><ol style="list-style-type: none">1. Programming is incorrect2. Water pressure is too low3. Particles of dirt or debris stuck in valve4. Faulty valve5. The faucet is off6. The batteries is low</div> <div data-bbox="1217 2040 1651 2090" data-label="Text"><p>Q: Do i have to keep my phone continuously in range for the timer to work</p></div> <div data-bbox="1217 2098 1651 2176" data-label="Text"><p>A: Once the program is set, it will run without your phone being near the device. You do have to be in range to change a program though</p></div> <div data-bbox="1217 2189 1549 2209" data-label="Text"><p>Q: Why irrigation recorded data will be lost?</p></div> <div data-bbox="1217 2220 1651 2297" data-label="Text"><p>A: When the timer connection exceeds the distance, the missing data. But does not affect the watering function of the equipment</p></div> <div data-bbox="1417 2414 1442 2433" data-label="Text"><p>11</p></div>	<div data-bbox="1707 2289 1787 2309" data-label="Section-Header"><h3>Support</h3></div> <div data-bbox="1707 2320 2134 2406" data-label="Text"><p>If you have any questions about our product, please feel free to contact us . We will followup and respond within 24 hours.</p></div> <div data-bbox="1934 2414 1959 2433" data-label="Text"><p>12</p></div>

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.