


# User Manual

## Bluetooth V5.3

Support IOS & Android System





## Easy Pairing

1.Before using this product, please put the two earbuds into the charging case and kindly have this product fully charged.It can be charged by the USB C cable via the socket at the back of the charging case. It will take about 2 hours for the charging.

2.Only need to open the charging case (keep the earbuds in the charging case), the Left earbud and Right earbud will connect automatically and enter into pairing mode for Bluetooth device.

3. Open the Bluetooth settings on your device. Search Bluetooth pairing name "ANC-T29E" Click to pair connection. You will hear a voice prompt when the connection is successful.

## Operation Guide




<b>L R</b>	One Touch :	Play/Pause/Answer/Hang Up
<b>L R</b>	Four Touch :	Activate the Voice Assistant
<b>L R</b>	Long Touch 2 Seconds:	Power On/Call Rejection
<b>L R</b>	Long Touch 5 Seconds:	Power Off
<b>L R</b>	Long Press 2 Seconds and Release:	ANC On/ANC Off/Transparency on
<b>L R</b>	Five Touch	Enter or exit the game mode
<b>L</b>	Double Touch : Volume Down Triple Touch : Prev. Song	<b>R</b> Double Touch : Volume Up Triple Touch : Next. Song

### Power On/Off

1)The earbuds will automatically power on when you open the charging case.Put the earbuds back into the charging case and close the cover to turn them off or press and hold the touch control surface for 8 seconds. They can also be powered on by holding the touch control surface for 2 seconds when they are not in the charging case.

2)To save battery time,the earbuds automatically turn off after 5 minutes of being out of range from their Bluetooth device.

## Charging Diagram




### Charger Case

Charging Time : About 2 hours

### Earbuds

When Charging : Charging case blue light.  
Full Charge: Charging case light went out  
Charging time : About 1 hour

## Product Detail




## Rest

Put the earbuds into the charging case and make sure that they are charging.Press the Reset button of charging case for 5 seconds until the LED indicator blink red and blue six times.

### Forcibly exit the device connection

Put the earbuds into the charging case and make sure that they are charging.Press the button of charging case for 2 seconds until the LED indicator blink blue six times.Then the earbuds will exit the existing device connection and enter into pairing mode for Bluetooth device.

## Wearing Diagram



## Specification

Pairing Name :	ANC-T29E
Bluetooth Version:	V5.4
Charging Voltage:	5V
Li-ion Battery :	3.7V/40mAh
Playing time :	up to 4.5H(ANC ON) up to 5H(ANC OFF)
Charging Time	about 1 Hours for earbuds
Profile Support :	HFP/A2DP/AVRCP
Active Noise Reduction Level:	20±2dB
Sensitivity :	96±3dB

Charging Case input power :	DC=5V 300mA
Charging Case output power:	DC=5V 40mA
Charging Case Li-ion Battery :	3.7V/500mAh
Charging Port :	USB Type C
Charging Time for Charging case :	about 2 Hours

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.