

**FCC WARNING**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



GUARANTEE
Non-human damage
12-month warranty

BASIC INFORMATION

Manual



Switch Puller



Keyboard



Type-C Cable



Receiver

● Size: 335.8(L)×155.5(W)×41.5(H)±2

● Layout: 82keys

● Backlight: RGB

● Switch: Mechanical switch


● Edition: USB/2.4G/BT

WIRED MODE

Toggle switch to OFF for Wired Mode.

Basculez le commutateur sur OFF pour passer en mode câblé

Interruptor de palanca a la posición de APAGADO



Fully charge keyboard before first use.

Rechargez complètement le clavier avant sa première utilisation

Cargue completamente el teclado antes de utilizarlo por primera vez

INDICATOR LIGHT

100%

IN WIRELESS MODE

BATTERY LEVEL

En modo inalámbrico: Nivel de batería

En mode sans fil: Niveau de batterie

○ Caps Lock

○ Win Lock

○ Scrlk Lock

○ Low-voltage Indication

○ Caps Lock

○ Win Lock

○ Scrlk Lock

○ Low-voltage Indication

○ Win Lock

○ Scrlk Lock

○ Low-voltage Indication

↓

Win Lock

Scrlk Lock

Low-voltage Indication

Scrlk Lock

Low-voltage Indication

Scrlk Lock

Low-voltage Indication

2.4GHZ MODE

Turn the toggle switch to the 2.4G position

Basculez l'interrupteur en position 2.4G

Comutador a la posición 2.4G

**BT MODE**

Toggle switch to BT for BT Mode.

Commutateur BT pour le mode Bluetooth

Comutador en posición BT



Short press Fn+Q/W/E to change BT channel.

Appuis Bref sur Fn+Q/W/E pour changer de canal Bluetooth


Pulsación corta Fn+Q/W/E para canal Bluetooth.



Long press Fn+Q/W/E entry pairing mode.

Appuis long sur Fn+Q/W/E pour entrer dans le mode d'appairage


Pulsación larga Fn+Q/W/E al modo de emparejamiento

THE SECOND COMBINATION OF FUNCTION KEYS

Switch to windows system

Basculez en mode système windows

Cambiar a Windows



Switch to mac system

Basculez en mode système mac


Cambiar a sistema mac



Pause

Pause

Pausa



Last song

Musique Précédente


Canción anterior



Play / pause

Lecture / Pause


Reproducir/pausar



Next song

Musique Suivante

Canción siguiente



Mute

Sourcine

Silenciar



Volume-

Diminuer le Volume

Volumen-



Volume+

Augmenter le Volume

Volumen+



Insert

Insérer

Insertar



ScrLK

ScrLK

ScrLK



PrtSc

PrtSc (Impression D'écran)

PrtSc

BACKLIGHT CONTROL

Switch Backlight Mode

Changement du mode de rétro-éclairage

Cambiar el modo de retroiluminación



Backlight Brightness-

Diminution de la Luminosité du rétroéclairage


Brillo de la retroiluminación-



Switch the backlight color

Changer la couleur du rétroéclairage

Cambiar el color de la retroiluminación



Backlight Speed-

Diminution de la Vitesse du rétroéclairage


Velocidad de retroiluminación-



Backlight Brightness+

Augmentation de la Luminosité du rétroéclairage+


Brillo de la retroiluminación+



Backlight Speed+

Augmentation de la Vitesse du rétroéclairage+

Velocidad de retroiluminación+



Restore to factory settings

Rétablir les paramètres d'usine


Restaurar valores de fábrica

CUSTOMIZED BACKLIGHT

Non-customizable

Non personnalisable

No personalizable



Non-personnalisable

No personalizable

Non personalizable



e.g.

**FCC WARNING**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.



GUARANTEE
Non-human damage
12-month warranty

BASIC INFORMATION

Manual



Switch Puller



Keyboard



Type-C Cable



Receiver

- **Size:** 335.8(L)×155.5(W)×41.5(H)±2
- **Layout:** 82keys

- **Backlight:** RGB
- **Switch:** Mechanical switch




- **Edition:** USB/2.4G/BT

WIRED MODE

拨动开关到OFF位置

Kippschalter auf die Position OFF
Portare l'interruttore in posizione OFF

首次使用前请为键盘充满电

Bitte laden Sie die Tastatur vor dem ersten Gebrauch
vollständig auf
Caricare completamente la tastiera prima del primo utilizzo**INDICATOR LIGHT**无线模式下
电池电量Im drahtlosen Modus: Batteriestand
In modalità wireless: livello della batteriaCaps Lock
Feststelltaste
Caps LockWin Lock
Win-Sperre
Win LockScrlk Lock
Scrlk-Sperre
Scrlk Lock低电压指示
Anzeige der niedrigen Spannung
Indicazione di bassa tensione**2.4GHZ MODE**

拨动开关到2.4G位置

Kippschalter auf die Position 2.4G
Commutare l'interruttore in posizione 2.4G

短按Fn+Q/W/E至蓝牙频道

Kurzes Drücken von Fn+Q/W/E zum
Bluetooth-Kanal
Premere brevemente Fn+Q/W/E per passare al
canale Bluetooth


长按Fn+Q/W/E进入配对模式

Langes Drücken von Fn+Q/W/E zum
Pairing-Modus
Premere a lungo Fn+Q/W/E per passare alla
modalità di accoppiamento**BT MODE**


拨动开关到BT位置

Kippschalter auf die Position BT
Commuta l'interruttore sulla posizione BT

短按Fn+Q/W/E至蓝牙频道

Kurzes Drücken von Fn+Q/W/E zum
Bluetooth-Kanal
Premere brevemente Fn+Q/W/E per passare al
canale Bluetooth**THE SECOND COMBINATION OF FUNCTION KEYS**

切换到windows系统


Schalter Im Windows-System
Passa a Windows

切换到mac系统


Schalter Im MAC-System
Passare al sistema Mac

停止


Pause




上一曲

Letzter Song
Canzone precedente


播放 / 暂停

Wiedergabe/Pause
Riproduzione/pausa


下一曲

Nächster Song
Canzone successiva

静音

Stummschaltung
Silenzioso

音量-

Lautstärke Verringern
Volume-

音量+

Lautstärke Erhöhen
Volume+

Insert

Einfügen
Inserire


Scrlk

ScrLK



PrtSc

PrtSc

CUSTOMIZED BACKLIGHT不可自定义
Nicht anpassbar
Non personalizzabile

重复按键可以改变背光颜色

Durch wiederholtes Drücken der Taste ändert sich die Farbe der Hintergrundbeleuchtung.

La pressione ripetuta dei tasti cambia il colore della retroilluminazione.

**BACKLIGHT CONTROL**

切换背光模式

Umschalten des Hintergrundbeleuchtungs modus
Commutazione della modalità di retroilluminazione

背光亮度-

Helligkeit der Hintergrundbeleuchtung-
Luminosità della retroilluminazione-

(only for RGB version)


切换背光颜色

Farbe der Hintergrundbeleuchtung wechseln
Cambiare il colore della retroilluminazione

背光速度-

Geschwindigkeit der Hintergrundbeleuchtung-
Velocità retroilluminazione-

背光亮度+

Helligkeit der Hintergrundbeleuchtung+
Luminosità della retroilluminazione+

背光速度+

Geschwindigkeit der Hintergrundbeleuchtung+
Velocità retroilluminazione+

恢复出厂设置

Werkseinstellungen wiederherstellen
Ripristino delle impostazioni di fabbrica**MULTIMEDIA KEY FOR WINDOWS**

计算机

Computer



浏览器

Browser



邮箱

Mailbox



计算器

Taschenrechner

Calcolatrice



播放器

Spieler

Lettore



停止

Anhalten

Arresto

MULTIMEDIA KEY FOR MAC

屏幕亮度-

Bildschirmhelligkeit-

Luminosità dello schermo-



屏幕亮度+

Bildschirmhelligkeit+

Luminosità dello schermo+



键盘背光亮度-

Helligkeit der Hintergrundbeleuchtung der Tastatur -

Luminosità della retroilluminazione della tastiera -



键盘背光亮度+

Helligkeit der Hintergrundbeleuchtung der Tastatur +



键盘背光亮度+

Helligkeit der Hintergrundbeleuchtung der Tastatur +

Luminosità della retroilluminazione della tastiera +

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.