

版本	标注	ECO编号	变更日期	变更描述	设计者
A01	NA	NA	2021.7.07	初版发行	李烜

QUICK START GUIDE

WYZE GUN SAFE

QUICK START GUIDE

IN THE BOX

Wyze Gun Safe	x 1
Backup Keys	x 2
AA Batteries	x 4
Mounting Screws	x 2
Quick Start Guide	x 1

1. Lock Catch
2. Cover Panel
3. Battery Cover
4. Emergency Power Port
5. Lock Cylinder
6. Fingerprint Scanner
7. Keypad
8. Interior LED Indicator
9. Eject Button
10. Pair Button

WARNINGS

To Prevent damage to your Wyze unit or injury to yourself or to others, read the following safety precautions before using this unit.

DO NOT place or store the backup keys inside the safe at any time. If the battery fails, you will be unable to open the safe.

DO NOT expose to extreme heat or cold. Battery power may be affected.

DO NOT store loaded guns in this unit. Firearms are serious in nature and must be handled with respect. Store responsibly.

DO NOT get fingerprint sensor wet.

ALWAYS check to make sure door has latched when closing; Lid requires a firm press and locks automatically.

DISCLAIMER

Neither seller nor manufacturer shall be liable for unauthorized access, any injury, loss or damage to personal property direct or consequential, arising out of the use of, or the inability to use the Wyze Safe.

The user shall determine the suitability of the Wyze Safe before the intended use and user assumes all risk and liability, whatsoever in connection therewith, Wyze Safe are not intended to protect against environmental hazards including fire and water.

Be sure and follow all local and state firearm laws.

DO NOT operate a firearm without proper training and experience.

SETUP

1. Battery Installation



Use the backup key to unlock the safe. The keyhole is located on left side of the safe underneath the hidden cover.

Press the ejection button to eject the battery case.


Install the included 4x AA batteries into the battery case. Insert the battery case back into the slot.

*Before device setup is completed, any fingerprint can open the safe. Please complete device setup immediately.

2. Download the Wyze app from the app store. Log in or create a Wyze account to finish Wyze Gun Safe setup.

3. Press the pair button for 3 seconds to enter pairing mode. Return to Wyze App on your smartphone and click on "Add Device." Select Wyze Gun Safe to begin device setup.



4. Follow the setup instructions in the Wyze App to complete Fingerprint and keypad access registration.

5. Once setup is completed, Wyze Gun Safe is ready for use.

BASIC OPERATIONS

Fingerprint Unlock

Place your finger on the fingerprint scanner to unlock the safe.

Keypad Unlock

Enter the correct (4-8 digit) access code on the keypad to unlock the safe.

Backup Key Unlock

Remove key cover and insert the backup key to unlock the safe.

LED STATUS LIGHT

Green light
Flash Once: Verification Successful
Flashing: Pairing Mode

Red light
Flash Once: Verification Failed
Flashing: Low Battery
Solid: 5 failed verification attempts

Green/Red Light
Flashing: Firmware update

MOUNTING INSTALLATION

You can securely mount your Wyze Gun Safe to a flat surface using the included mounting screws and the pre-drilled holes on the bottom of the safe.

Using the Mounting Screws

1. Make sure you have enough clearance for the lid to open properly before mounting the safe.
2. Position the safe on a flat surface where you want to mount it.
3. Use a pencil to mark the holes for drilling.
4. Drill pilot holes.
5. Position safe in place and install the mounting screws through the safe and into the pilot holes. Tighten screws to complete installation.

Caution: Mounting the safe vertically so that the door flips upward will result in incomplete opening due to the weight of the lid. The door will open if the safe is mounted vertically so that the door opens down or to the side.

FAQ

What are the benefits of using Wyze app with the Wyze Gun Safe?

How do I turn off audio?

Any tips on improving fingerprint sensor accuracy?

SPECIFICATION

Product name: Wyze Lock Safe
Model: WSGS
Product size: L315mmxW262mmxH87mm(Exterior) /L269mmxW158mmxH66mm(Interior)
Product weight: 5.64kg
Battery type: 4x AA alkaline batteries
Operating temperature: -10°C-50°C
Operating humidity: ≤95%RH
Warranty: 1 Year
Certification: FCC/CA65/TSCA Test ICA California DOJ Certification

FCC WARNING


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Bluetooth® and associated logos are registered trademarks owned by Bluetooth SIG, Inc. Any use of such marks by Wyze Labs Inc. is permitted under license. Other trademarks and trade names are those of their respective owners.

NEED HELP?

Contact our support team at:
<https://support.wyze.com>
Join our community:
<https://wyze.com/community>





备注：

1. 尺寸：100*153mm

2. 印刷颜色：4C

3. 符合云丁科技《有害物质管理标准》

材质：108g哑粉,4C,折页,										SCALE				
表面处理：哑油										SHEET				
SELECT			V							UNIT mm	物料名称：说明书			
Dim	TOL.	A	B	C	EPS	EPE	EPP	BAG	CTN					
0~6	0.05	0.05	0.10											
6~30	0.10	0.15	0.20	0.50	0.50	0.50	3.00		0.20					
30~120	0.15	0.20	0.30	0.50	0.50	0.50	5.00	1.00	0.25					
120~300	0.20	0.30	0.40	1.00	1.00	1.00	10.00	1.00	0.30					
300~450	0.25	0.40	0.50	2.00	2.00	2.00	15.00	2.00	0.50					
450~600	0.30	0.50	0.60	3.00	3.00	3.00	20.00	3.00	0.80		VOLVO	0524083001	李烜	周树温
DRAFT TOLERANCE			± 0.20°			CRITICAL DIM. MARK			*					