

DIGITAL PORTABLE RADIO

**OWNER'S MANUAL** 



#### **Preface**

Welcome to the world of Hytera and thank you for purchasing this product. This manual includes a description of the functions and step-by-step procedures for use. It also includes a troubleshooting guide. To avoid bodily injury or property loss caused by incorrect operation, please carefully read the Safety Information Booklet before use.

This manual is applicable to the following product:

BD61X Digital Portable Radio (X may represent 0, 2, 5, 6 or 8).

## **Copyright Information**

Hytera is the trademark or registered trademark of Hytera Communications Corporation Limited (the Company) in People's Republic of China (PRC) and/or other countries or areas. The Company retains the ownership of its trademarks and product names. All other trademarks and/or product names that may be used in this manual are properties of their respective owners. The product described in this manual may include the Company's computer programs stored in memory or other media. Laws in PRC and/or other countries or areas protect the exclusive rights of the Company with respect to its computer programs. The purchase of this product shall not be deemed to grant, either directly or by implication, any rights to the purchaser regarding the Company's computer programs any not be copied, modified, distributed, decompiled, or reverse-engineered in any manner without the prior written consent of the Company.

#### Disclaimer

The Company endeavors to achieve the accuracy and completeness of this manual, but no warranty of accuracy or reliability is given. All the specifications and designs are subject to change without notice due to continuous technology development. No part of this manual may be copied, modified, translated, or distributed in any manner without the prior written consent of the Company.

We do not guarantee, for any particular purpose, the accuracy, validity, timeliness, legitimacy or completeness of the Third Party products and contents involved in this manual.

If you have any suggestions or would like to receive more information, please visit our website at: http://www.hytera.com.

#### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Verification of harmful interference by this equipment to radio or television reception can be determined by turning it off and then on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a different circuit to that of the receiver's outlet
- Consult the dealer or an experienced radio/TV technician for help.

  Operation is subject to the following two conditions:
- This device may not cause harmful interference.

 This device must accept any interference received, including interference that may cause undesired operation.

Note: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Compliance with RF Exposure Standards

Hytera's portable radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR § 1.1307, 1.1310 and 2.1093.
   American National Standards Institute (ANSI) Unstitute of Electrical
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1:2005; Canada RSS102 Issue 5 March 2015.
- Institute of Electrical and Electronic Engineers (IEEE) C95.1:2005
   Edition

# RF Exposure Compliance and Control Guidelines and Operating Instructions

To control your exposure and ensure compliance with the occupational/controlled environment exposure limits always adhere to the following procedures.

#### Guidelines:

· Do not remove the RF Exposure Label from the device.

- User awareness instructions should accompany device when transferred to other users.
- Do not use this device if the operational requirements described herein are not met

#### Operating Instructions:

- Transmit no more than the rated duty factor of 50% of the time. To transmit (talk), push the Push-To-Talk (PTT) button. To receive calls, release the PTT button. Transmitting 50% of the time, or less, is important because the radio generates measurable RF energy only when transmitting (in terms of measuring for standards compliance).
- Keep the radio unit at least 2.5 cm away from the face. Keeping the radio at the proper distance is important as RF exposure decreases with distance from the antenna. The antenna should be kept away from the face and eyes.
- When worn on the body, always place the radio in a Hytera-approved holder, holster, case, or body harness or by use of the correct clip for this product. Use of non-approved accessories may result in exposure levels which exceed the FCC's occupational/controlled environmental RF exposure limits.
- Use of non-approved antennas, batteries, and accessories causes the radio to exceed the FCC RF exposure guidelines.
- · Contact your local dealer for the product's optional accessories.

#### IC Statement

The device has been tested and complies with SAR limits, users can obtain Canadian information on RF exposure and compliance

Après examen de ce matériel aux conformité aux limites DAS et/ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes.

# L'exposition aux champs rf de conformité et de contrôle d'orientations et instructions

Pour contrôler l'exposition et s'assurer de la conformité avec les limites d'exposition professionnelle / environnement contrôlé, toujours respecter les procédures suivantes.

Lignes directrices:

Ne pas enlever l'étiquette de l'appareil d'exposition aux radiofréquences.

Sensibilisation des utilisateurs instructions devraient accompagner dispositif lorsque transférés à d'autres utilisateurs.

Ne pas utiliser cet appareil si les exigences opérationnelles décrites ci - après ne sont pas remplies.

Les instructions de fonctionnement:

Transmettre non plus que le facteur d'utilisation nominal de 50% du temps. à transmettre (parler), pousse le pousse à parler (ptt). Pour recevoir des appels, les ptt.50% du temps de transmission, ou moins, est important parce que la radio génère de l'énergie rf seulement lors de la transmission des (en termes de mesure de la conformité aux normes).

le groupe de la radio continue d'au moins 2,5 cm de la surface, garde la radio à la bonne distance est important, car l'exposition aux champs rf diminue avec la distance de l'antenne.l'antenne doit se tenir loin du visage et des yeux. Quand portés sur le corps, toujours place de la radio dans un étui, hytera approuvé titulaire, ou un harnais ou par l'utilisation de la vidéo pour ce produit.utilisation des accessoires non approuvés peuvent entraîner des fac qui dépassent les niveaux d'exposition professionnelle et environnementale contrôlée des limites d'exposition aux rf.

Les opérations doivent satisfaire aux deux conditions suivantes:

Ce dispositif peut ne pas causer d'interférences nuisibles.

Ce dispositif doit accepter toute interférence reçue,
Y compris les interférences qui peuvent provoquer des accidents.Operation

Non approuvé des antennes, les piles et les accessoires causes la radio à dénasser les lignes directrices sur l'exposition aux radiofréquences de fac-

Communiquez avec votre distributeur local pour les accessoires facultatifs du produit.

SAR tests are conducted using standard operating positions accepted by the FCC/ISEDC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

Before a new model device is a available for sale to the public, it must be tested and certified to the FCC/ISEDC that it does not exceed the exposure limit established by the FCC/ISEDC, Tests for each device are performed in positions and locations (worn on the body)as required by the FCC/ISEDC. For face-up, 25mm was used for test, this equipment should be installed and operated with minimum distance 25mm.

For body worn operation, this device has been tested and meets the FCC/

Tor body with objectatori, this excite has been tested and needs the PCF ISEDC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Les essais SAR sont effectués à l'aide de positions d'exploitation normalisées acceptées par la FCC/ISEDC avec l'appareil transmettant à son niveau de puissance certifié le plus élevé dans toutes les bandes de fréquences testées, bien que le SAR soit déterminé au niveau de puissance certifié le plus élevé, le niveau réel de R-S de l'appareil pendant son fonctionnement peut être bien inférieur à la valeur maximale. Avant qu'un nouveau dispositif de modèle ne soit disponible à la vente au public, il doit être testé et certifié à la FCC/ISEDC qu'il ne dépasse pas la limite d'exposition établie par la FCC/ISEDC, les tests pour chaque appareil sont effectués dans des positions et des emplacements (portés sur le corps)

Pour le face-vers le haut, 25mm a été utilisé pour l'essai, cet équipement doit être installé et actionné avec une distance minimale de 25mm.

comme l'exige la FCC/ISEDC.

Pour un fonctionnement porté sur le corps, cet appareil a été testé et répond aux directives d'exposition RF FCC/ISEDC lorsqu'il est utilisé avec un accessoire conçu pour ce produit ou lorsqu'il est utilisé avec un accessoire qui ne contient pas de métal.

Le non-respect des restrictions ci-dessus peut entraîner une violation des lignes directirecs sur l'exposition aux RF.

#### **EU Regulatory Conformance**

As certified by the qualified laboratory, the product is in compliance with the essential requirements and other relevant provisions of the following directives: 1999/5/EC or 2014/53/EU, 2006/66/EC, 2011/65/EU, and 2012/19/EU.

Please note that the above information is applicable to EU countries only.

## Contents

Items in the Package	2	Product Care
Product Overview	3	Product Cleaning
Product Controls	3	Optional Accessories
LED Indication	4	
Before Use	4	
Attaching the Antenna	4	
Attaching the Battery	4	
Attaching the Belt Clip	4	
Attaching the Accessories	4	
Charging the Battery	4	
Checking the Battery Power	5	
Basic Operations	5	
Call Services	6	
Call on Digital Channel	6	
Call on Analog Channel (Without Signaling)	6	
Optional Features	7	
Troubleshooting	8	
Care and Cleaning	9	

)r	ntional Accessories
	Product Cleaning
	Product Care

# Items in the Package


Please unpack carefully and check that all items listed below are received. If any item is missing or damaged, please contact your dealer.

Item	Quantity (PCS)	Item	Quantity (PCS)
Radio	1	Antenna	1
Battery	1	Belt Clip	1
Charger	1	Strap	1
Power Adapter	1	Documentation Kit	1

The frequency band is marked on the antenna label; if unavailable,

# **Product Overview**

## **Product Controls**



Horse

 $\ensuremath{ \stackrel{\bullet}{\bigcirc}}$  You can adapt your radio to use the  $S\!K$  as the shortcut to a radio feature.

#### LED Indication

LED Indicator	Radio Status	
Flashes green	Being turned on.	
Glows green	Receiving.	
Glows red	Transmitting.	
Flashes orange slowly	Scanning.	
Glows orange	Call hang time: No voice is being transmitted or received on the channel during a call. Within such a period, you can hold down the PTT key to speak.	

#### **Before Use**

#### Attaching the Antenna

Do not hold the radio by its antenna, as it may reduce the radio **Euripe** performance and life span of the antenna.

- 1. Place the antenna in its receptacle.
- 2 Rotate the antenna clockwise

#### Attaching the Battery

- Insert the top end of the battery into the top of the battery slot.
- 2. Press the bottom end of the battery until the latch snaps into place.



To remove the battery, make sure that the radio is turned off, and then slide the battery latch upwards to unlock the battery.

## Attaching the Belt Clip

- 1. Unfasten the two screws on the back of the radio
- 2. Align the screw holes on the belt clip with those on the back of the radio.
- 3. Tighten the screws.

## **Attaching the Accessories**

- 1. Loosen the screw on the accessory connector cover, and then open the cover
- Plug the accessory into the accessory connector.
- 3. Tighten the screw on the accessory plug.

## Charging the Battery



Use the charger specified by the Company to charge the battery.

Be sure to charge the battery fully before initial use, since reduction of state of charge (SoC) may lead to low battery alarm. You can charge the standalone battery or the radio with battery attached. It is recommended that your radio remain powered off during charging.



The LED indicator on the charger shows the charging status. For details, see the following table.

LED Indicator	Charging Status	
Glows green	The battery is inserted incorrectly or fully charged.	
Glows red	The battery is charging.	
Glows orange	The battery is charged to 85% or above.	

## **Checking the Battery Power**

You can check the current battery power by pressing and holding the **Battery Power Indicator** key programmed by your dealer, and release the key to exit. The following table lists battery power indications.

LED Indicator	Alert Tone	Battery Power
Glows green	Three beeps	High
Glows orange	Two beeps	Medium
Glows red	One beep	Low
Flashes red	Low battery tone	Under the low battery threshold.  Please recharge or replace the battery.

# **Basic Operations**

If you want to	Do this
Turn on the radio	Rotate the On-Off/Volume Control knob clockwise.
Turn off the radio	Rotate the On-Off/Volume Control knob counterclockwise.
Increase/Decrease the volume	Rotate the On-Off/Volume Control knob clockwise/counterclockwise after turning on the radio.
Select a channel	Rotate the Channel Selector knob.

## **Call Services**

## Call on Digital Channel

On the digital channel, you can initiate or respond to a group call or private call. A group call is a call from an individual user to a group of users. A private call is a call from an individual user to another individual user.

#### **Initiating a Call**

- 1. Select the required channel.
- 2. Hold the radio vertically 2.5 to 5 cm from your mouth.
- 3. Press and hold the PTT key and speak when the radio is in standby mode.

#### Receiving and Responding to a Call

When receiving a call, you can listen to it without any operation. You can press and hold the **PTT** key to respond within the preset time period.

## Call on Analog Channel (Without Signaling)

A call on analog channel is from an individual user to all users on the channel. The operations are the same as the call on digital channel.

# Optional Features

The following features need to be programmed by your dealer. Please contact your dealer for detailed operations.

Type	Feature	Description	
	Zone	Allows you to select a zone. The radio supports up to 3 zones, with a maximum of 16 channels per zone.	
	Power Level	Allows you to switch the transmit power level between high and low.	
	Scan	Allows the radio to scan all channels in the scan list programmed for the current channel.	
	Emergency Alarm	Allows you to initiate an emergency alarm or call at any time to ask for help in case of emergencies.	
	Voice Operated	All C C C C C C C C C C C C C C C C C C	
Radio	Transmit (VOX)	Allows you to enjoy hands-free communication with the dedicated VOX earpiece.	
Feature Busy Channel Busy Chann		D	
	Lockout	Prevents the radio from transmitting on a busy channel.	
	Time-out Timer	Toming to the control of the control	
	(TOT)	Terminates transmission when the preset time period expires.	
	Battery Save	Allows the radio to automatically enter the battery save mode when detecting no activity or operation within a certain time	
		period.	
Digital	All Call	Allows you to initiate a call to all users on the channel.	
Digital One Touch Call Allows you to press one key to call the predefined private or group contact.		Allows you to press one key to call the predefined private or group contact.	
Feature	TDMA Direct Mode	Allows the radio to operate on a channel with two time slots.	
	Squelch Off	Allows the radio's speaker to always keep unmuted.	
Analog	Squelch Level Allows you to adjust the squelch threshold required for the radio to unmute.		
Feature Monitor Allows the radio to monitor activities on the channel.  CTCSS/CDCSS Allows you to prevent unwanted calls on the same frequency.		Allows the radio to monitor activities on the channel.	
		Allows you to prevent unwanted calls on the same frequency.	

# Troubleshooting

Phenomena	Analysis	Solution
	The battery may be installed improperly.	Remove and reattach the battery.
The radio cannot be	The battery power may run out.	Recharge or replace the battery.
turned on.	The battery may suffer from poor contact caused by dirty or	Clear the bettery contests or realises the bettery
	damaged battery contacts.	Clean the battery contacts or replace the battery.
During reception, the	The battery voltage may be low.	Recharge or replace the battery.
voice is weak, intermittent	The volume level may be low.	Increase the volume.
or totally inactive.	The antenna may be loose or may be installed incorrectly.	Turn off the radio, and remove and reattach the antenna.
of totally mactive.	The speaker may be blocked.	Clean the surface of the speaker.
	The frequency or signal strength may be low in comparison	Verify your TX/RX frequency and signal strength are correct.
You cannot communicate	to other members.	verify your TA/KA frequency and signar strength are correct.
with other group members.	The channel type (digital or analog) may be set incorrectly.	Verify you are on the correct digital or analog channel.
	You may be too far away from other members.	Move towards other members.
Unknown voices or noise	You may be interrupted by radios using the same frequency.	Change the frequency, or adjust the squelch level.
is heard on the channel	The radio in analog mode may be set with no signaling.	Set signaling for all radios operating at the same frequency to avoid
is neard on the channel.	The radio in analog mode may be set with no signating.	interference.
	You may be too far away from other members.	Move towards other members.
You are unable to hear anyone because of too much noise and hiss.	You may be located in an unfavorable position. For	Manager de la constant de la constan
	example, your communication may be blocked by high	Move to an open and flat area, and restart the radio and try
	buildings or blocked in an underground area.	contacting again.
	It could be the result of external disturbance (such as	Character State of the Committee of the
	electromagnetic interference).	Stay away from equipment that may cause interference.

If the above solutions cannot fix your problems, or you may have some other queries, please contact us or your local dealer for more technical support.

## Care and Cleaning

To guarantee optimal performance as well as a long service life of the product, please follow these tips.

#### **Product Care**

- Do not pierce or scrape the product.
- Keep the product far away from substances that can corrode the circuitry.
- · Do not hold the product by the antenna or earpiece cable.
- · Close the accessory connector cover when no accessory is in use.

#### **Product Cleaning**



Turn off the product and remove the battery before cleaning.

- Clean up the dust and fine particles on the products surface and charging piece with a clean and dry lint-free cloth or a brush regularly
- Use neutral cleanser and a non-woven fabric to clean the keys, knobs and front case after long-time use. Do not use chemical preparations such as stain removers, alcohol, sprays or oil preparations, so as to avoid surface case damage.
- · Make sure the product is completely dry before use.

## **Optional Accessories**



Use the accessories specified by Hytera only; otherwise, the Company will not be liable for any loss or damage arising out of the use of any unauthorised accessories.

Contact your local dealer for the optional accessories used with the product.



is the trademark or registered trademark of Hytera Communications Corporation Limited. @2016 Hytera Communications Corporation Limited. All Rights Reserved. Address: Hytera Tower, Hi-Tech Industrial Park North, 9108# Beihuan Road, Nanshan District, Shenzhen, People's Republic of China Postcode: 518057

http://www.hytera.com

## Hytera

是海能达通信股份有限公司的注册商标或商标 ②2016 海能达通信股份有限公司。版权所有

地址:深圳市南山区高新区北区北环路9108号海能达大厦邮编:518057

服务热线: 400-830-7020

http://www.hytera.com

Z17714 W17431 L07157

