

TWS: (True Wireless Speaker)

It needs two speakers to make a TWS. When you had twospeakers, you can make a TWS as below steps:

1. Don't connect to this speaker with Bluetooth devices.
2. Turn on both speakers and press the mode button to changeto Bluetooth mode.
3. Press and hold one speaker's play/pause button for 3seconds and wait for both speakers to connect each other. It will have a tone coming out from these speakers after connected successfully.
4. Turn the Bluetooth devices to search the Bluetooth name“TK-502” and tap to connect it. It will have a tone coming out from this speaker after connected successfully.
5. Now you can play the music form your Bluetooth devices.

Playing recording function

1. After the portable speaker is tured on, insert the TF Card or U disk to the TF slot or USB port, press the Mode button to the Bluetooth mode, connect it with your Bluetooth device and paly the music, press the REC button seconds you will here a prompt voice “ding” means the TF card/USB is starting recording, you will here prompt voice”ding ding”, that means stop recording.
2. If you want to play this recording sound, press the Mode button to the USB or TF card mode, press the next button to find out this song and play it.

Note■

- a)When your TF card and U disk insert to the speaker at same time, it will record to your U disk when recording
- b)The recording only works in Bluetooth mode, can not record in FM, Aux mode and can't record Microphone's sound.
- c)It's better to tum the Bleutooth devices volume to maximum during recording
- d)It will be stopped recording when pressing the mode button during recording.

Specifications:


Power:	40W
Frequency Response	
for main speaker:	45Hz-20KHz
Power Supply:	DC 9V

PORTABLE BATTERY SPEAKER

User Manual TK-502



Front panel



- 1.DC interface (9V)
- 2.USB Player
- 3.TF card input
- 4.AUX input
- 5.Microphone input
- 6.VOLUME Music volume adjust
- 7.MENU: Choose pressTREBLE,BASS,ECHO,MIC VOLUME;Press "Menu" button, then twist the Volume knob to choose among "T-12--12,b-12--12, 0U 00-16,E 00-16"
- 8.REC button
- 9.MODE/MIC.PRI:Short press BLUE,AUX,FM;long press MIC.PRI ON/OFF.
- 10.Power (Hold for 3 seconds to ON/OFF).
- 11.Previous/CH-: In the state of FM radio, short press CH- for the last available radio program.
- 12.Play/Pause&TWS&FM:(Wirless Bluetooth Connection: under bluetooth mode, press TWS button for around 3 seconds to pairing another TWS speaker;Under FM mode, lightly press Play/Pause&TWS to enter into automatic scan and all the scanned radio stations will be saved automatically.)
- 13.Next/CH+:In the state of FM radio, short press CH+ for the next available radio program.
- 14.LED mode
- 15.LED Display

POWER SOURCE

- 1.Please charge the unit at least 4 hours before first time using.
2. Power (Hold for 3 seconds to ON/OFF).

CHARGE THE BATTERY

When charging,the battery symbol on the screen flashing. When the unit is fully charged,the battery symbol stop flashing.

1. Connect the adapter cable to the DC9V interface of the speaker firmly.
2. When the battery is fully charged, please disconnect the USB charge cable from the speaker.
- 3.The speaker works normally when charging.

POWER/VOLUME

Twist the dial clockwise/anticlockwise to increase/discrease the volume.

PREVIOUS/NEXT BUTTON

Under playing status, press PREVIOUS/NEXT button to get back to a previous or next song.

PAUSE/PLAY BUTTON

To stop playing the current track, please press PAUSE/PLAY button on the control panel. Press it once again to continue playing.

MODE

Press to enter into playing mode selection(Bluetooth,FM Radio,AUX Input,USB,TF).

AUX IN JACK

- 1.Connect an audio cable to the AUX IN JACK of the speaker and to the audio output socket on the external audio devices such as MP3 player, discman,etc,then select LINE by pressing the MODE button on the control panel .
- 2.Play from an external audio device.

MIC IN JACK

Plug in microphone directly for playing.

USB JACK

Insert USB card directly for playing.

TF JACK

Insert TF card dirctly for playing.

FM FUNCTION

Press MODE button to switch to FM mode. Press PLAY/PAUSE button on control panel for automatic searching and saving the radio stations, by pressing PREVIOUS or NEXT you can select a previous or next radio station.

Bluetooth:

Press MODE button on control panel to select Bluetooth mode.

Simultaneously open the Bluetooth setting on your phone, tablet or any other bluetooth enabled audio device and select "TK-502"(no need to match code), the unit and device will then connected via Bluetooth. Press the "NEXT SONG" and "PREVIOUS SONG" button on the control panel to select the song, press "PLAY/PAUSE" button to control the playing status.

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.